

Sommario

DC10ElGear	3
<i>IMPLEMENTATION</i>	3
Error	3

DC10ElGear

D = Device(CAMMING2, CAMMING3)


C = Calculation functions

Lo scopo della DC10ElGear funzione is to calculate the areas of electronic cam for managing a slave of a Gearing.

The gearing is a system that links a Slave axis an axis Master by a ratio of timing adjustable.

Below is a chart showing the progress of the Slave respect to Master. The zero point on the graph represents the time when given the command to STARTCAM the Slave. The ratio set in the sample chart is 1:2 (aslParam[1] = 500)

N.B.: The stretch marked as "tacc" there may be no if you set the acceleration time to zero. With zero acceleration time Slave's departure is to "step", reached in 'zero time' the speed of the Master.



IMPLEMENTATION

DC10ElGear (aslParam, codeG, codeM, codeQm, codeQs, codeQma, codeQsa,Error)

Parameters:

IN/OUT	VARIABLE TYPE	EXAMPLE NAME	DIM	
IN	ARRSYS	aslParam [1]	L	Synchronous Slave/Master relationship (1000=1:1) (possibility of minimum variation of 1‰)
IN	ARRSYS	aslParam [2]	L	Maximum speed Slave (UM/sec) [1÷999999]
IN	ARRSYS	aslParam [3]	L	Acceleration time Slave to go from zero to max speed. Setting 0 the start is to "step". (s/100) [1÷999999]
IN	ARRSYS	aslParam [4]	L	Master reference speed, used to calculate the accelerations (UM/sec) [1÷999999]
IN	ARRSYS	aslParam [5]	L	"Measure" parameter of used device [1÷999999]
IN	ARRSYS	aslParam [6]	L	"Pulse" parameter of used device [1÷999999]
OUT	ARRSYS	CodeG	L	Array containing calculated G Code (40 elements) (OUT)
OUT	ARRSYS	CodeM	L	Array containing claculated M Code (40 elements) (OUT)
OUT	ARRSYS	CodeQm	L	Array containing calculated CodeQm (40 elements) (OUT)
OUT	ARRSYS	CodeQs	L	Array containing calculated CodeQs (40 elements) (OUT)
OUT	ARRSYS	CodeQma	L	Array containing CodeQma (40 elements) (OUT)
OUT	ARRSYS	CodeQsa	L	Array containing CodeQsa (40 elements) (OUT)
OUT	SYSTEM	Error	B	Var of occurred error (OUT)

Error

After calling the function, the error variable takes certain values, the meaning of these values is summarized below:

0: calculation executed without errors

1: Sync ratio equal to 0

2: Slave max speed less than or equal to 0

3: Master speed less than or equal to 0

4: "Measure" parameter less than or equal to 0

5: Calculated Slave speed greater than the maximum Slave speed

Example

In our example, we want to calculate the cam shaft when the gfCalcElGear flag goes to 1. Writing on the cam is done by the DW20WrCam function.

```

MAIN:
  IF gfCalcElGear
    gfCalcElGear = 0
    aslParam[1] = 2000 ;Slave/Master relationship (2:1)
    aslParam[2] = 4000 ;Maximum Slave speed
    aslParam[3] = 0 ;Acceleration Slave time (0=disabled:starting without ramps)
    aslParam[4] = 1500 ;Master reference speed
    aslParam[5] = 1000 ;"Measure" parameter of device
    aslParam[6] = 4000 ;"Pulse" parameter of device

    DC10ElGear (aslParam, codeG, codeM, codeQm, codeQs, codeQma, codeQsa, Error)
    IF NOT Error
      SettIniz = 1
      NumSet = 4

      DW20WrCam (cmCamma, CodeG, CodeM, CodeQm, CodeQs, CodeQma, CodeQsa, SettIniz, SettFine, NumSet, Error)
    ENDIF
  ENDIF

```

Operation notes

- The sync relationship (aslParam[1]) can also be set to negative, in that case the Slave follows the relationship of timing set but going in the back direction.
- The acceleration time set is used to decide the ramp by which the Slave, at the time of the command lock cam (STARTCAM), must engage in synchronism with the Master. If the time is set to zero the Slave makes a step to reach immediately the Master speed
- The sectors number used is always 4
- If you want to change "on the fly" the sync relationship, this you can only do this by using the **DC10ChGear** function

Documento generato automaticamente da **Qem Wiki** - <https://wiki.qem.it/>

Il contenuto wiki è costantemente aggiornato dal team di sviluppo, è quindi possibile che la versione online contenga informazioni più recenti di questo documento.