

Inhaltsverzeichnis

DW22WrCam	3
IMPLEMENTATION	3
Use mode	3
Error	3

DW22WrCam

D = Device(CAMMING2, CAMMING3, CAMMING4)

W = Writing functions

***** = Replaces the function **DW20WrCam**

The DW22WrCam function is used to write the fields to build an electronic cam. The function you will need to pass as parameters a pointer to start and end time they serve to identify the field where you want to start writing and the area where you want to stop. Function writes 40 sectors cam.

IMPLEMENTATION

DW22WrCam (cmCamma, aslParam, CodeG, CodeM, CodeQm, CodeQs, CodeQma, CodeQsa, Error)

Parameters:

IN/OUT	VARIABLE TYPE	EXAMPLE NAME	DIM	
IN	CAMMING2 CAMMING3 CAMMING4	cmCamma	-	Type of device to which you can apply the function
IN	ARRSYS	aslParam[1]	L	Sector number to start writing
IN	SYSTEM	aslParam[2]	L	Sector number to end writing (valid only if 'aslParam[3]' is to 0)
IN	SYSTEM	aslParam[3]	L	Number of sectors to write (optional if you want to use 'aslParam[2]')
IN	SYSTEM	aslParam[4]	L	Number of array element from which to begin reading values (if set 0 it start with the first element)
IN	ARRSYS	CodeG	W/L	Array containing Code G calculated
IN	ARRSYS	CodeM	W/L	Array containing Code M calculated
IN	ARRSYS	CodeQm	L	Array containing calculated space Master
IN	ARRSYS	CodeQs	L	Array containing calculated space Slave
IN	ARRSYS	CodeQma	L	Array containing Qma code (auxiliary code)
IN	ARRSYS	CodeQsa	L	Array containing Qsa code (auxiliary code)
OUT	SYSTEM	Error	B	Error var on the cam writing

Use mode

The „aslParam[1]“ parameter (starting sector) indicates the number of the field in which you want to start writing the cam, while „aslParam[4]“ (initial array element) indicates the number of the element of the array (CodeG, CodeM, etc..) from which you will start to copy the values in the fields.

If the „aslParam[2]“ parameter (ending sector) is not set to 0, writing the fields ends with sector of this number, If the parameter is to 0 the writing continues for the number of sectors set in „aslParam[3]“ parameter (number of sectors to write).

Error

Once invoked the function if there are any errors the error variable takes certain values, the meaning of these values is described below:

0 - No error

1 - Indices of the start and/or end writing drivers

Example

```

MAIN:
IF gfScrittCam
gfScrittCam = 0
aslParam[1] = 1 ;He started writing from 1° sector of the cam
aslParam[4] = 10 ;Start reading from 10th element of the array
DW22WrCam cmCamma, aslParam, CodeG, CodeM, CodeQm, CodeQs, CodeQma, CodeQsa, Error)
IF sbErrore
JUMP FINE
ENDIF
ENDIF

```

Documento generato automaticamente da **Qem Wiki** - <https://wiki.qem.it/>

Il contenuto wiki è costantemente aggiornato dal team di sviluppo, è quindi possibile che la versione online contenga informazioni più recenti di questo documento.