

## Table of Contents


<b>MMF_P1R44F-024: Start-Up Manual</b>	3
<b>1. Information</b>	3
<b>1.1 Release</b>	3
Specifications	3
<b>2. Settings</b>	4
<b>Machine Overview</b>	4
<b>2.1 Belt Settings</b>	5
Belt Axis Resolution	5
<b>2.2 Setting Bridge</b>	6
Bridge Alignment / Sensor Bar	6
Bridge Resolution	6
<b>Bridge Calibration</b>	7
Calibration	7
<b>Setting Gantry</b>	8
Gantry Alignment / Sensor Bar	8
Gantry Resolution	8
<b>Gantry Calibration</b>	9
Calibration	9
Dynamic Calibration	11



# MMF\_P1R44F-024: Start-Up Manual

## 1. Information

### 1.1 Release

			
<b>Document:</b>	mmf_p1r44f-024		
<b>Description:</b>	Start-Up Manual p1r44f-024		
<b>Writer:</b>	Andrea Zarantonello		
<b>Approver:</b>	Giuliano Tognon		
<b>Link:</b>	<a href="https://www.qem.eu/doku/doku.php/en/strumenti/qmoveplus/c1r44/p1r44f-024/mmf_p1r44f-024">https://www.qem.eu/doku/doku.php/en/strumenti/qmoveplus/c1r44/p1r44f-024/mmf_p1r44f-024</a>		
<b>Language:</b>	English		
<b>Document Release</b>	<b>Description</b>	<b>Notes</b>	<b>Date</b>
01	New manual		15/01/2023

## Specifications

The copyright of this manual is reserved. No part of this document may be copied or reproduced in any form without the prior written permission of QEM.

QEM makes no representations or warranties with respect to the contents and specifically disclaims any implied warranties of fitness for any particular purpose. The information in this document is subject to change without notice. QEM assumes no responsibility for any errors that may appear in this document.


Trademarks:

QEM® is a registered trademark.

## 2. Settings

### Machine Overview

Machine top view :




n:	Description:
1	Raw Slab
2	Conveyor Encoder
3	Limit Switch Bar
4	Conveyor Belt
5	Mobile Bridge
6	Grinding Heads
7	Inlet Roller

2.1 Belt Settings

Belt Axis Resolution



Procedure	
1	Make a mark on the belt and correspondingly on the fixed part
2	Zero the ENCODER value using the  button
3	Move the belt about 4000 mm approximately
4	Set the PULSE parameter value to the number read in the ENCODER parameter
5	Measure the distance between the mark on the fixed part and the mark on the belt
6	Enter the measurement in the "MEASURE" field



## Bridge Calibration

**Important:** parameters must be adjusted: inverter / brushless driver / servo valve to eliminate ramps (ramps will be managed by the instrument)

### Calibration

1	Using the "Resolution" page, move the bridge axis to the center of the stroke.
2	Zero it with the " = 0 " button
3	go to the " BRIDGE CALIBRATION " page

**TARATURA PONTE MASTER**

**CALIBRAZIONE**

**OFF**

OUT TENSIONE 99999999 U

OFFSET 99999999 U

**A** **-** **+**

VELOCITA 99999999 mm/s  
99999999 Hz

MAX VELOCITA 99999999 mm/s

POSIZIONE **= 0** 99999999 mm  
9999999999

POSIZIONE SLAVE 99999999 mm

DISALLINEAMENTO 99999999 mm

**POSIZIONATORE**

**STOP**

DELTA 99999999 mm

SET VELOCITA 99999999 mm/s

TEMPO ACC. 99999999 s

TEMPO DEC. 99999999 s

FEEDFORWARD TMP 99999999 %

PROP. GAIN TMP 99999999

T INTEGRALE 99999999 s

MAX ERR. INSEG. 99999999 mm

TEMPO INVERSIONE 99999999 s

FEEDFORWARD 99999999 %

PROP. GAIN 99999999

ERRORE INSEG. 99999999 mm

ERR. MAX. ASSE + 99999999 mm

ERR. MAX. ASSE - 99999999 mm

**RESET**

4	Disconnect the control conductors (+/-10 Volt) Inverter/Driver/Servo Valve
5	Calibrate the Inverter/Driver/Servo Valve devices to have high sensitivity
6	Short-circuit the analog control inputs of the Inverter/Driver/Servo Valve devices
7	Calibrate the Offset of the Inverter/Driver/Servo Valve device so that the bridge axis is still
8	Connect the analog control conductors to the Inverter/Driver/Servo Valve
9	Press the " A " button, the instrument will automatically calculate the OFFSET voltage
10	Move the bridge axis to 1/5 of the stroke
11	Enter the value 1 V in the "OUT VOLTAGE" field
12	Read the speed
13	Multiply the speed value by 10, then enter it in the "maximum speed" field

Setting Gantry

Gantry Alignment / Sensor Bar

To align the gantry with the sensor bar, the homing sensor (or zero sensor) on the gantry must be aligned with the first sensor on the sheet detection bar.

Gantry Resolution



RISOLUZIONE PONTE



ENCODER  
99999999



PULSE  
99999999  
MEASURE  
99999999

ASSE  
MASTER

-

= 0

+

ENCODER  
99999999



PULSE  
99999999  
MEASURE  
99999999

ASSE  
SLAVE

-

= 0

+








= enable/disable gantry button.



= gantry disabled



= gantry enabled

Procedure	
1	Press the " - " button, the tool delivers -1 Volt
2	Press the " + " button, the tool delivers +1 Volt
3	Press the " - " button, move the gantry axis towards one end (do not activate the limit switch)
4	Make a mark on the moving part, and correspondingly, make a mark on the fixed part
5	<div></div> <div>Zero the <b>ENCODER</b> value with the button</div>
6	Using the " + " button, move the axis towards the opposite end (do not activate the limit switch)
7	Measure the distance between the mark on the fixed part and the mark on the moving part
8	Enter the measurement in the "MEASURE" field



## Gantry Calibration

**Important:** You will need to adjust the parameters of the inverter/Driver Brushless/servo valve to eliminate the ramps (the ramps will be managed by the tool).


### Calibration

1	Using the "RESOLUTION" page, move the gantry axis to the center of its travel
2	Zero it with the " = 0 " button
3	Go to the "GANTRY CALIBRATION" page

4	Disconnect the control conductors (+/-10 Volts) Inverter/Driver/Servo valve
5	Calibrate the Inverter/Driver/Servo valve devices to have high sensitivity
6	Short-circuit the analog control inputs of the Inverter/Driver/Servo valve devices
7	Calibrate the offset of the Inverter/Driver/Servo valve device to keep the gantry axis still
8	Connect the analog control conductors to the Inverter/Driver/Servo valve devices
9	Press the "A" button, the tool will automatically calculate the OFFSET voltage
10	Move the gantry axis to 1/5 of its travel
11	Enter a value of 1 V in the "OUT VOLTAGE" field
12	Read the speed
13	Multiply the speed value by 10 and enter it in the "maximum speed" field

**Attention:** If the automatic offset voltage calculation procedure (step 9) fails, perform the following manual procedure:  
Determine :

with which positive voltage value the gantry moves forward with which negative voltage value the gantry moves backward  
Then, set the voltage offset halfway between these two values  
Example :



## Dynamic Calibration


1	Move the gantry to 1/5 (20%) of its travel
2	Press the " = 0" button
3	Enter a value in the "DELTA" field, equal to 4/5 (80%) of its travel
4	Set T INTEGRAL = 0
5	Set FEEDFORWARD TMP = 100
6	Set PROP.GAIN TMP = 0.02
7	Set TEMPO ACC = 3
8	Set TEMPO DEC. = 3
9	Set MAX ERR. INSEG. = 9999
10	Set the speed value to 30% of the maximum speed
11	Press Start
12	The gantry will start to oscillate

Perform the following activities repeatedly, calmly, with the following goals:

highest possible speed shortest possible acceleration ramps low tracking error Procedure:

1	Slightly increase the PROP.GAIN TMP parameter (e.g., 0.03...0.04...0.05...)
2	Observe if the tracking error is less than 30 mm
3	Then, slightly decrease TEMPO ACC and TEMPO DEC
4	Slightly increase the PROP.GAIN TMP parameter again
5	Observe if the tracking error is less than 30 mm
6	Increase the speed from 30% to 40%
7	Slightly increase the PROP.GAIN TMP parameter again

Repeat steps 1 to 7 until the axis vibrates. When the axis vibrates, set PROP.GAIN TMP to -10%




	Description	Parameter
1	Acceleration in the positive direction	PB 06
2	Constant speed	
3	Deceleration	PB 07
4	Acceleration in the negative direction	PB 07
5	Constant speed	
6	Deceleration	PB 07
7	Pause	PB 09

Note: Acceleration/deceleration with "S" ramps (parameter "PG 34") reduce the number of back-and-forth cycles but contribute to a smoother gantry motion.



## Tracking Error Setting:



With the gantry in motion, lower the tracking error value (following error) from 9999 to 100. Gradually reduce it from 100 towards 0000. Once you find the value that triggers the alarm, add 15%. Caution: The MAX and min tracking errors must be less than 30.

The "RESET FOLL.ERR" button allows you to recalculate the maximum and minimum following error. Press it each time you change the parameters for dynamic calibration.

Perform the same procedure on the slave gantry calibration page if you are using a second (slave) motor.



Then enable the gantry by pressing the enable button



Check that the button turns green and try moving the master gantry, ensuring that the slave gantry moves in sync with the master.

Documento generato automaticamente da **Qem Wiki** - <https://wiki.qem.it/>

Il contenuto wiki è costantemente aggiornato dal team di sviluppo, è quindi possibile che la versione online contenga informazioni più recenti di questo documento.