

Índice


P1K31FR30-001 - 3 axis bridge saw: User Manual	3
Tabela de conteúdos	4
1. General Characteristics	4
1.1 Typical work results	6
2. Hardware J1-K31-FR30	7
2.1 Function Keys and LEDs	7
2.2 Symbols and keys	8
3. STARTUP	8
4. Main Menu	9
5. Homing	10
5.1 Homing Procedure	10
6. Machine Data	11
7. Manual/Semiautomatic	12
8. Multiple Cuts	15
8.0.1 No Rotating Table	16
8.0.2 Rotating Table	16
8.0.3 Axis parameters	17
8.0.4 Work Parameters	18
9. Tilted Cuts	19
9.0.1 Work Parameters	20
10. Programs	21
10.0.1 Program List Filters	21
10.1 PROFILES	23
10.1.1 PROFILE - CAD	25
10.1.2 PROFILES - CAM	29
10.2 TOPS	31
10.2.1 TOPS - CAD	32
10.2.2 DISK CUT - CAM	35
10.2.3 MILL CUT - CAM	36
11. WORK PROGRAMS	43
11.1 Run a Program	43
11.1.1 Work Program type 0 (Profili dritti)	44
11.1.2 Work Program type 0 (Profili sagomati)	47
11.1.3 Work Program type 1 or 2 (Profili sagomati)	49
11.1.4 TOPS Work Program	50
12. ISO G codes	50
13. Alarms	51
13.1 Alarm History	52
13.2 Warning Messages	53
14. Diagnostics	54
14.1 CPU DATA	55
14.2 Inputs	55
14.3 Outputs	55
14.4 Encoder Counts	55
14.5 Analog outputs	55
14.6 Controllo dei fincorsa	56

P1K31FR30-001 - 3 axis bridge saw: User Manual

PS Bernard sistemare la tabella a "10.2.3.1.2. POCKETING - Parametri lavorazione "Tasca""

Mi manca da

- rimuovere le immagini dei zeri profili
- aggiornare elenco allarmi (ma spetto versione definitiva)
- aggiornare elenco warnings



Quality in Electronic
Manufacturing

Document	P1K31FR30-001		
Description	User manual		
Drawn up	Riccardo Furlato		
Approved	Draft		
Link:	http://www.qem.eu/doku/doku.php/en/strumenti/qmoveplus/j1k31/mdu_p1k31fr30-001/funzionamento		
Languages	English		
Release	Description	Notes	Date
01	New Manual		26/05/14

All rights reserved on this manual. No part of this document can be copied or reproduced in any form without prior written authorisation. QEM does not insure or guarantee its contents and explicitly declines all liability related to the guarantee of its suitability for any purpose. The information in this document can be changed without notice. QEM shall not be held liable for any error or omission in this document. QEM® is a registered trademark. Microsoft® and MS-DOS® are registered trademarks and Windows® is a trademark of Microsoft Corporation.

Tabela de conteúdos

- P1K31FR30-001 - 3 axis bridge saw: User Manual
- 1. General Characteristics
 - 1.1 Typical work results
- 2. Hardware J1-K31-FR30
 - 2.1 Function Keys and LEDs
 - 2.2 Symbols and keys
- 3. STARTUP
- 4. Main Menu
- 5. Homing
 - 5.1 Homing Procedure
- 6. Machine Data
- 7. Manual/Semiautomatic
- 8. Multiple Cuts
 - 8.0.1 No Rotating Table
 - 8.0.2 Rotating Table
 - 8.0.3 Axis parameters
 - 8.0.4 Work Parameters
- 9. Tilted Cuts
 - 9.0.1 Work Parameters
- 10. Programs
 - 10.0.1 Program List Filters
 - 10.1 PROFILES
 - 10.1.1 PROFILE - CAD
 - 10.1.2 PROFILES - CAM
 - 10.2 TOPS
 - 10.2.1 TOPS - CAD
 - 10.2.2 DISK CUT - CAM
 - 10.2.3 MILL CUT - CAM
- 11. WORK PROGRAMS
 - 11.1 Run a Program
 - 11.1.1 Work Program type 0 (Profili dritti)
 - 11.1.2 Work Program type 0 (Profili sagomati)
 - 11.1.3 Work Program type 1 or 2 (Profili sagomati)
 - 11.1.4 TOPS Work Program
- 12. ISO G codes
- 13. Alarms
 - 13.1 Alarm History
 - 13.2 Warning Messages
- 14. Diagnostics
 - 14.1 CPU DATA
 - 14.2 Inputs
 - 14.3 Outputs
 - 14.4 Encoder Counts
 - 14.5 Analog outputs
 - 14.6 Controllo dei finecorsa

1. General Characteristics

Description

The **P1K31FR30 - 001** software can be installed on the **Qmove+ J1-K31-FR30, J1-P31, J1-P51, J1P71** hardware and is designed to control a bridge saw with 3 to 5 axes, for marble and granite. The salient features of the **P1K31FR30 - 001** are described below.

Axes

- Axes X, Y, Z controlled by PID on space (brushless motors with servo drives and brushless motors).
- Axis W for the table rotation is manually controlled, with the operator entering the position on the controller
- Axis H for the disk inclination is manually controlled, with the operator entering the angle on the controller

Optional

- Axis W for the table rotation, with positioning accounting for inertia (asynchronous motor and V/F inverter) without interpolation.
- Axis H for the disk inclination, with positioning accounting for inertia (asynchronous motor and V/F inverter) without interpolation.

Work Processes

- Semiautomatic functions for positioning the axes and for single cuts.
- Multiple cuts for block and slab cutting, with table rotation (W) for tile cutting.
- Straight profiling with horizontal or vertical disk.
- Step cutting with inclined disk (on machines that have disk inclination).
- Straight profile finishing, using the face of the disk (interpolation of YZ).

Drawing

- Profile programming by a miniCAD, embedded on the controller.
- Import of profiles, saved on DXF file, by the "Profile Importer" conversion software (optional).

Work modes

- Repeat the programmed shape.
- Set the precision of the finishing.
- Modify the speed of disk motion during the work cycle.
- Compensation of the disk thickness and the disk diameter

Accessory functions, messages and alarms

- Select the language
- View the profile and the disk position, during the work cycle.
- Diagnostics of the inputs and the outputs.
- Backup and restore of the data on non volatible memory (FLASH EPROM).
- Messages for active faults, to assist troubleshooting.
- Help Messages.
- Modbus interface for reading the absorbed current of the disk.






Optional Features (some not documented in this manual)

- Profiles made with rotating table (similar to a vertical lathe).
- Profiling with horizontal disk or vertical disk (XZ or XY interpolation).
- Copying by photocell from a cardboard shape or black drawing on a whiteboard.
- ISO manager with G code interpreter


Modbus Interface

- The USER serial port can create a MODBUS RTU (RS485) network, for reading the disk rpm.
- Serial port connection for a magnetic rule, for reading the absolute position of the axis.

1.1 Typical work results

 Multiple cuts	 Tile cuts	 Arc tiles
 Profile roughing	 Profile finishing	 Curved profile roughing
 Column roughing	 Column finishing	 Horizontal profile roughing
 Circular Top roughing	 Spiral stairs	 G-code relief
 Top milling	 Sinks & drains	 G-code texting

2. Hardware J1-K31-FR30




2.1 Function Keys and LEDs

Key	Icon	Function	Led	Key	Icon	Function	Led
F1...F3		Not Used		F11		Semiautomatic = ON	Semiautomatic status
F4		Enclosures	Enclosure open status	F12		Table UP	Table up
F5	-	Not used		F13		Table DOWN	Table Down
F6		Y Laser ON/OFF	Laser status	F14		Table Rotation Anticlockwise	-
F7		X Laser ON/OFF	Laser status	F15		Table Rotation Clockwise	-
F8		Water ON/OFF	Water status	F16		Disk ON/OFF	Blink is starting, On is started
F9		Alarm = ON	-	F17		Mill ON/OFF	Blink is starting, On is started
F10		Quit or prolonged MAIN	-				


2.2 Symbols and keys

Button	Description	-----	Top Bar Symbol	Description
	Press to confirm			Manual
	Select			Emergency
	Previous screen			Automatic
	Next screen			Function mode
	Reserved Area			Not initialized
	Open file on SD card			Setup Locked/Unlocked
	Save			
	Work preview			
	Yellow settings can be changed			

3. STARTUP



4. Main Menu




6. Machine Data


MAIN MENU




→



→







→










Set Default Z min position 	Auto-set Z min position 	Set SAFE HEIGHT 
 Disk RPM	 Disk diameter	 Set diameter and RPM
 Disk absorbed current	 Set Maximum current	 Set Disk thickness
 Start position	 Park position	 Change tool position
DISK DIAMETER & RPM		
 Disk diameter	 Marble	 Granite
 9999999 AUTO RPM AUTO RPM based on diameter - Set RPM override of auto		

7. Manual/Semiautomatic







					
	Go to START		Go to PARK		Go to TOOL CHANGE
					
SET TARGET POSITION 9999 mm	☒ ABSOLUTE TARGET POSITION ☒ INCREMENTAL TARGET POSITION ☒ AUTO-SET ZERO POSITION 			Auto-set ZERO position 	
				Disk Correction  OFF  ON	

		Z jog  Default Z min  Auto-set Z min 
		
		

	Auto-set position		X Start Cut position		X end Cut position
	Single cut		Step cuts with multiple depth increases		Cut depth
Number of Steps (max 10) 		Step depth for (X+)		Step depth for (X-)	
Last cut direction 		Last cut depth		% Speed change of Last Cut	

8. Multiple Cuts

8.0.1 No Rotating Table



1 Target count and position
2 Work step now
3 Cut width (Y)
4 Number of cuts to make
5 Piece counter
6 Scroll work program list
7 Work Parameters
8 Cutting depth (Z)

8.0.2 Rotating Table










1 Target count and position
2 Work step now
3 Cut width (Y)
4 Number of cuts to make
5 Piece counter
6 Scroll work program list
7 Work Parameters
8 Cutting depth (Z)
9 Table Rotation (W)

8.0.3 Axis parameters


X	NO ROTATING TABLE X AXIS WORK PARAMETERS		WITH ROTATING TABLE X AXIS WORK PARAMETERS	
			Auto-set position X1 + X2 = table (W) at 0°..... X3 + X4 = table (W) at 90° N.B. the disk exits the slab by its radius before reaching X1 - X2 or X3 - X4 .	
Y	Y AXIS WORK PARAMETERS			
	Auto-set Y2 = start position with table (W) at angle			
		X Start position		X End position
Z	Z AXIS WORK PARAMETERS - 99 + 999999 999999 999999 999%			
	Advance 99999	Number of Steps - 0 ~ 10 +	Last cut direction	
	Step depth for (X+) cut		Step depth for (X-) cut	
	Last cut depth		Last cut % Speed change	

8.0.4 Work Parameters

		
Y DIRECTION	POSITIVE direction to end of cut 	NEGATIVE direction to end of cut 
CUT DIRECTION	X+ only 	TWO-WAY Cut 
CUT TYPE	SINGLE cut 	STEP cut 
Z UP	Z UP when X is at min position 	X and Z exit slab TOGETHER 
END POSITION	Disk STOPS at end of work 	Disk goes to PARK at end of work 
ROTATION	NO ROTATING TABLE 	WITH ROTATING TABLE 

9. Tilted Cuts





MAIN MENU







I/O







PIECE COUNT
999999







TILTED CUTS

X 99999999

Y 99999999

Z 99999999

99999999

99999999

PROGRAM 99

PIECE COUNT 999

MEASURE N.

99 999999 9999

99 999999 9999

99 999999 9999

99 999999 9999

99 999999 9999


PAR

+


-

99999999

X





Z




PAR



		1 Axis parameters Target count and position 2 Work step now 3 Cut width (Y) 4 Number of cuts to work 5 Piece counter 6 Scroll work program list 7 Work Parameters 8 Cutting depth (Z) 9 Set disk angle (H)
	Axis parameters - see Multiple Cuts	

9.0.1 Work Parameters

		
Y DIRECTION	POSITIVE direction to end of cut 	NEGATIVE direction to end of cut 
CUT DIRECTION	X+ Cut only 	TWO-WAY Cut 
THICKNESS TYPE	Thickness at 90° to the cut 	Thickness PARALLEL to the slab surface 
DEPTH TYPE	Depth = along the disk 	Depth = 90° to the slab surface 
END POSITION	Disk stops at end of work 	Disk goes to PARK at end of work 

10. Programs

The diagram illustrates the navigation flow for program management, starting from the **MAIN MENU** and moving through **PROGRAM MANAGEMENT**, **PROGRAM TYPE**, **PROGRAM EDIT**, and finally to the **PROGRAM EDITOR**.

MAIN MENU: Displays icons for I/O, I/O, and I/O. A hand icon points to the I/O icon.

PROGRAM MANAGEMENT: Displays a list of programs (e.g., 99999-99-99/99/99). A hand icon points to the **PAGE** button.

PROGRAM TYPE: Displays icons for different program types (e.g., 99999-99-99/99/99). A hand icon points to the **PROGRAM TYPE** button.

PROGRAM EDIT: Displays a form for editing a program (e.g., 99999-99-99/99/99). A hand icon points to the **PROGRAM EDIT** button.

PROGRAM EDITOR: Displays the program editor interface (e.g., 99999-99-99/99/99). A hand icon points to the **RUN** button.

10.0.1 Program List Filters




Using the program's list filters is possible to get quickly the desired program, rather than scroll entire available list. The system permit two type of filtering which can be combined each other:

- Filter on program description
- Filter on program type

Warn that “**Type**” mean:

Type	Description
0	Show any program
1	Show only tagli sagomati/profilatura programs
2	Show only fresatura programs
3	Show only taglio poligoni programs






10.1 PROFILES






		
		
		
		
		
		

			   LOAD OBJECTS FROM SD CARD?  SAVE OBJECTS ON SD CARD? 	   NEW PROGRAM?  SAVE OVER 99% ? 
--	--	--	---	--

10.1.1 PROFILE - CAD


		Copy		Mirror copy		Delete the object Z0 = origin Y coordinate = 0	
		Zoom in		Zoom-out		Fit to screen	
		YZ plane = Profile shape				XZ plane = Curved profile	
			Scroll and select a line				
		Add a line		Insert a line		Delete a line	
Line Options							
	Absolute position from origin				Incremental position from start of line		
-----	-----	-----	-----	-----	-----	-----	

LINE 		Enter the end point
TANGENT LINE 		OR enter Y (or X)  OR enter Z (or Y)  OR enter L = length 
RADIUS ARC 		Enter End point and Radius MINIMUM the minimum radius possible  clockwise  anticlockwise  Also enter the curve direction  clockwise OR  anticlockwise  small arc OR  wide arc The screen shows the minimum radius possible

3 POINT ARC 		Enter End point and Middle point 
TANGENT ARC 		Enter End point 
TRANSFER 		Movement with no cut. Enter target point 
		
The software automatically corrects an undercut profile line  Fix Me! see other manual		

Profiles with straight cuts


Draw a profile on the Y-Z plane

- vertical disk 
- horizontal disk 

Never draw profiles on the other planes.


Profiles with curved cuts

1. Draw a profile on the usual Y-Z plane


- vertical disk 
- horizontal disk 

2. Draw the curved cut

- on X-Z plane for vertical disk



- on X-Y plane for horizontal disk




To change plane touch the



immagine stessa.

10.1.2 PROFILES - CAM



PROFILING PARAMETERS

LV= 9999999

LZ= 9999999

LX= 9999999

SM= 999999

SM

D= 99999

B.W. 99999

NP= 999

SP= 9999999

CUT DIRECTION

V DIRECTION

+

↓

FINISHING PARAMETERS

DX = 999999

U = 999999 mm/min

OZ = 999999

OFF ON ONLY








+

↓


PROFILING PARAMETERS

SPEED= 99999 mm/min


Profile Finishing is NOT possible on curved profiles.

Slab size. Optionally you can enter slab size. It will draw in gray color both in cad page and in preview page 	Extra Material on the profile 		Cut X+ only  Two-way Cut 	Y direction  
Cut Spacing type 	Cut spacing D=99999  Spacing along profile 	Disk diameter B.W. 99999  Cut Preview  Spacing along Y Critical points ON 	Spacing along Y Critical Points OFF 	
Repeat - Vertical Disk 	Repeat - Horizontal Disk 	NP = Number of Repeats SP = Space between repeats		
	Work sequence OFF Profile only ON = Profile and Finishing ONLY = Finishing only	DX = Disk path spacing V = Finishing speed OZ = Finishing depth		
	Curved profiles. Set the maximum cut speed.			

10.2 TOPS





10.2.1 TOPS - CAD

	
	Drawings are always made with positive X and Y.
Fit to screen 	Zoom in Zoom out Touch to center a point on Fix Me!
	Scroll and Select objects. The selected object is black. Other objects are yellow. X0 99999999 Y0 99999999 Origin of the object.

	Object tools	
 Add new object	 Delete all objects	 Delete object
 Copy an object COPY 9999999999 9999999999 	 Move an object MOVE 9999999999 9999999999 	 Rotate an object ROTATE A 999999999° 
 Resize an object SCALE FACTOR 9999999999 	 Mirror copy an object MIRROR 	 Draw a Parallel edge PARALLEL OFFSET 9999999999 TYPE Inside 

10.2.1.1 CAD Tools

LINE - 999 + CAD Line tools		
- 000 +	Scroll and select a line Line properties	
Add line	Insert line	Delete line
MACROS Automatic CAD functions		
Rettangle.	RECTANGLE H 9999999999 W 9999999999 MACRO	H = height W = width.
Regular Polygon	POLYGON R 9999999999 N 9999999999 L 9999999999 MACRO	N = number of sides R radius OR L length of side
L Shape	TOP H 9999999999 W 9999999999 L 9999999999 K 9999999999 MACRO	H W L K as shown
Ellipse.	ELLIPSE A 9999999999 B 9999999999 9999999999 9999999999 MACRO	A = diameter 1 B = diameter 2
Irregular Polygon	STAIR N 99999999 AC 99999999 AB 99999999 BD 99999999 BC 99999999 CE 99999999 CD 99999999 DE 99999999 MACRO	As shown

LINES	Line drawing tools	
	Absolute positions = from origin	
	Incremental positions = from end of last line	
LINE 		Enter the end point
TANGENT LINE 		Y (or X) axis Z axis OR Length
RADIUS ARC 		Radius Arc Enter the end point and radius Also enter the curve direction  clockwise OR  anticlockwise  small arc OR  wide arc The screen shows the minimum radius possible
3 POINT ARC 		Arc through 3 points Enter the middle point and end point
TANGENT ARC 		Arc at a tangent to the previous line Enter the end point (the others are automatic)
TRANSFER 		Transfer with no cut Enter the point to start work again. The transfer line is not cut

10.2.2 DISK CUT - CAM

 Fix Me!

 Fix Me!

Mettere il numero di tipo PROFILE-TOP-DISK CUT in ogni sezione

	Tool on left or outside		Tool on right or inside		Extra material on edge
	Slab thickness		Extra Corner Cut		Shorter Corner Cut
	Extra depth into table		H = Slab length L = Slab width  Fix Me!		Tangent retta Disk Segment of Arc Cut
-----	-----	-----	-----	-----	-----


10.2.3 MILL CUT - CAM




















	Set Tool Diameter		Set Cutting Speed		Set Z- Down Speed
	Cut on left		Cut on right		
	SINGLE cut to full depth		STEP cuts with increasing depth		Step depth
Sloping cut function - Direction of slope					
	Depth increase = X increase		Depth increase = X decrease		
	Depth increase = Y decrease		Depth increase = Y increase		
	Start depth		Final depth		Cut order, normal (from start point to endpoint) or reverse (from end point to start point).

	PP = Start point Set the start point of the work
Closed object 	Open ended object 
	 Open ended objects must start at an end
CLOCKWISE 	ANTICLOCKWISE 
 Direction of First Cut	Not valid for open ended objects
	ENTRY/EXIT Set an approach path for the tool. L = straight section R = radius of a curved section.
	
 ENTRY PATH	 EXIT PATH
 Closed objects and inside cuts do not ENTER/EXIT on corners	

10.2.3.1 TOPS - CAM Program

Symbols on Objects

The selected line is red

End of line

3 POINT ARC

The middle point

Start of an object

Scroll and Select from CAM list						
		Add a CAM		Delete a CAM		CAM properties
	Fit to screen		Zoom in		Zoom out	
Set the CAM						
		Work OK		Work OFF		CAD object modified
		CAM In Program		CAM Not in Program		

Select object

Mill Cut

Core Drill

Recess


Mill

Recess

3D

Disk Cut


10.2.3.1.1 CORE DRILL RECESSING



L'area interna di una geometria chiusa viene svuotata tramite foratura. Tale lavorazione calcola la posizione dei fori secondo una modalità impostata con i seguenti parametri.

	Set Tool Diameter		AUTOMATIC drilling		Press START to drill each hole
	Edge hole spacing		Extra space between holes and inside edge		
	X hole spacing		Y hole spacing		
Hole Path Layout					
	EDGE holes along inside edge		HOR horizontal path		VER vertical path
	EDGE+HOR inside edge + horizontal		EDGE + VER inside edge + vertical		
	First depth of drilling		First drilling speed		
	Final drilling depth		Final drilling speed		
	P1 must be less than P2		V1 is normally less than V2		


10.2.3.1.2 MILL RECESSING




	Set drill diameter		Space between tool paths		extra material along inside edge
Fix Me!					
TI: Direction of slope					
	Depth increase = X increase		Depth increase = X decrease		Start depth of slope
	Depth increase = Y decrease		Depth increase = Y increase		Final depth of slope
	If Start depth and Final depth are equal = no slope				
	HORIZONTAL tool paths along X		VERTICAL tool paths along Y		SPIRAL tool paths in concentric circles.
	VZ = Z- down speed		VT = Cutting speed		

	SINGLE Depth cut in one stroke.		 Fix Me! STEP Depth cut in several steps.		Depth increase at each STEP
---	---	---	--	---	------------------------------------

10.2.3.1.3 3D RECESSING







3D Recessing applied to a rectangle



	Set tool diameter		Depth at edge		Depth at drain center
	- RE = Outside radius - RI = Inside radius - RS = Drain radius (all at center depth)		PB = Cut spacing on edge of slab		PR = Cut spacing on outside radius
	X position of drain center		Y position of drain center		Extra material along inside edge
	Z- down speed		Cutting speed		

11. WORK PROGRAMS

11.1 Run a Program



The minimum and maximum limits = slab size + disk radius



Fix Me!

dimensione blocco??



Fix Me!

quota di correzione???



MACHINE START.



Fix Me!

La successione dei tagli compone la sgrossatura del profilo. L'asse X si muoverà sempre tra le due quote autoapprese che dovranno essere esterne al blocco da lavorare.




Fix Me!

A questo punto può essere eseguita la finitura se il selettore della finitura è stato impostato su **CONTINUA** (se impostato su **OFF** la finitura verrà saltata, se impostato su **SOLO** la finitura verrà eseguita subito, senza eseguire la sgrossatura).



Fix Me!

Per eseguire l'operazione di finitura la lama si porta sulla quota di **X autoappresa minima + quota di correzione** e quindi esegue una serie di passate in interpolazione YZ in accordo con i parametri per la finitura impostati. La finitura finisce quando si arriva alla quota **X autoappresa massima - quota di correzione** (vedi esempio).





Nel dare start al ciclo automatico verrà richiesta un'operazione di azzeramento delle quote degli assi.

GRANDE



Fix Me!





Fix Me!




Fix Me!


11.1.2 Work Program type 0 (Profili sagomati)




I tagli vengono realizzati in successione con un'unica passata (marmo) oppure ad incrementi successivi (granito) in accordo con i parametri impostati in precedenza. La successione dei tagli compone la sgrossatura del profilo. I tagli vengono eseguiti partendo dalla quota X autoappresa minima aggiungendo due tratti orizzontali lunghi come il raggio della lama, prima e dopo il profilo disegnato.



Si potranno presentare quindi due casi:



In questo caso la larghezza del profilo sommato al diametro della lama è maggiore della distanza tra le due quote di X autoapprese. Come si vede dalla figura, il taglio parte alla quota minima autoappresa e viene eseguito completamente fino a superare la quota X massima autoappresa.




In questo caso la larghezza del profilo sommato al diametro della lama è minore della distanza tra le due quote di X autoapprese. Come si vede dalla figura, il taglio parte alla quota minima autoappresa, mentre il tratto orizzontale finale viene prolungato fino a portare il centro della lama sulla quota X autoappresa massima.




Il processo di finitura non è previsto per le lavorazioni di taglio curvilineo.

Questa schermata spiega che la lama deve essere portata a sfioro del blocco (come rappresentato), prima di dare l' OK per l'azzeramento delle quote degli assi.



11.1.3 Work Program type 1 or 2 (Profili sagomati)



Nella pagina di esecuzione 2D è possibile lanciare l'esecuzione di un programma 2D. Nella lista di lavorazioni sono evidenziate a gruppi di 5 in un menu scorrevole le singole operazioni che compongono il programma. Durante l'esecuzione verrà visualizzata l'esecuzione della lavorazione in maniera simile a quanto ottenuto in fase di programmazione.



Nel dare start al ciclo automatico verrà richiesta un'operazione di azzeramento delle quote degli assi.

11.1.4 TOPS Work Program



12. ISO G codes

	Optional accessory requiring QEM Isomanager (see specific manual  insert link)
	When using an SD card rename the .hex file with a number (0 ~ 999999). (file name: 1.hex, 2.hex...)


Program State

Run Mode	1: read from SD card read file from a Memory card 2: read from PC read file from the PC connection 3: save on SD card only save file from PC to SD card
SD card program number	the .hex file number in the SD card.
Read status	the percentage progress of reading the file on SD card.
Block Executed	ISO instructions executed.
G code of actual line num.	the actual ISO instruction number.
G code actual line	the actual ISO instruction.

Program settings

		Run ISO from SD card Run ISO from internal memory Run ISO from remote Run ISO from remote and save on internal memory Only save ISO on internal memory
--	--	--

13. Alarms



Alarms block the machine operation.

Alarm	Cause	Solution
Emergency	Manual emergency stop	-
Y limit switch backward	Y-axis at minimum LS	-
Y limit switch forward	Y-axis at maximum LS	-
Z limit switch backward	Z-axis at minimum LS	-
Z limit switch forward	Z-axis at maximum LS	-
X limit switch backward	X-axis at minimum LS	-
X limit switch forward	X-axis at maximum LS	-
H limit switch backward	H-axis at minimum LS	-
H limit switch forward	H-axis at maximum LS	-
Disk not running	Disk must be running in automatic cycle	-
Water pressure	No cooling water	The water valve shut
Disk motor overcurrent	The disk motor current absorption is over the threshold	-
Z Following error	The axis follow error is over the maximum threshold	-
Y Following error		-
X Following error		-
Interpolation fault	Error during axis interpolation	One axis over the maximum position
Thermic fault	Overload of drivers tripped	-
Driver is fault	Fault in one of the axis drivers	-
X encoder fault	Axis encoder malfunctioning	-
Y encoder fault		-
Z encoder fault		-
W sensor missing	Low table sensor may be disconnected	-
Y Axis out of tolerance	Axis positioning out of tolerance	Check axis setup parameters
Z Axis out of tolerance		
W Axis out of tolerance		
H Axis out of tolerance		
CAN module - data error	CAN module error	Check CAN communication or cable
CAN module - no communication	CAN module not responding	
SD CARD not present	Error in SD card upload/download	Check the MMC/SD support, check the correct procedure
MMC/SD error update		
MMC/SD file not open		
MMC/SD file not create		
MMC/SD error write		
MMC/SD error seek		
MMC/SD error read		
MMC/SD error read seek		
MMC/SD error read format		
MMC/SD error record		
MMC/SD error delete		
MMC/SD error max retry		
MMC/SD undefined error		

Alarm	Cause	Solution
INT: motion mode not defined	Interpolation interpreter error	-
INT: exact path mode not supported		
INT: invalid instruction		
INT: invalid version		
INT: invalid release		
INT: spindle management		
INT: change tool management	Interpolation execution error	
Mechanical components activation error		
INTERP writing error		
INTERP starting error		

13.1 Alarm History



ALARM HISTORY 99/99

idx	date	hour	num	par1	par2
1-1	99/99/9999	99:99	999	99999	99999
2-1	99/99/9999	99:99	999	99999	99999
3-1	99/99/9999	99:99	999	99999	99999
4-1	99/99/9999	99:99	999	99999	99999





 to cancel Alarm History

13.2 Warning Messages

Messages do not block the machine operation.



controllare con qpaint

Message	Cause	Solution
PLEASE WAIT... Fix Me!	Data being processed	-
WAITING FOR POWER SYSTEM	Fix Me!	Check the emergency button is not pressed
PATH Fix Me! ERROR	There is an error in the path settings, Fix Me! before the process.	The path may be too long
DISK TILT ERROR	The disk or tool tilt is not correct for the work cycle	Correct the disk or tool tilt
WORK DONE	Automatic cycle is completed successfully	-
X POSITION NOT OK	X position is incorrent	X position is outside the auto-set min-max positions
RUN HOMING	The Homing is not OK	Run the homing procedure

14. Diagnostics

14.1 CPU DATA

CPU DATA		
Fw name:	AAAAA - 99.9.99	Fw name : firmware code and relative checksum Task time : average CPU cycle time Maximum Time and Minimum Time indexing for the scan CPU time : total time CPU is in RUN state (hh:mm)
(Fw check.:	999999999999 dec)	
Task time:	99999 ms	
Max task time:	99999 ms	
Min task time:	99999 ms	
CPU time:	99999:99	

14.2 Inputs

INPUTS	State of digital inputs																				Analog input readings				BOURNS input reading

Legend:
 = OFF
 = ON

BOURNS input reading:

14.3 Outputs

OUTPUTS	State of the digital outputs.																			

Legend:
 = OFF
 = ON

14.4 Encoder Counts

COUNTS	COUNTERS										Axis position	

Legend:
 = OFF
 = ON

FOLLERR: 9999999
 MAX: POS: 9999999, NEG: 9999999
FOLLERR: = realtime following error
MAX: POS:/NEG: = min - max follow errors

14.5 Analog outputs

ANALOG OUTS	ANALOG OUTPUTS				Analog output voltage

14.6 Controllo dei finecorsa

Controllo dei finecorsa hardware

Controllo dei finecorsa 0° - 90° del disco



Disk auto speed table (password)



Fix Me!

Va su installazione non qui

Tool compensation limits




Fix Me!

The compensation del tool diameter nelle lavorazioni 2D consente di determinare il percorso che l'utensile di un certo diametro deve compiere per ottenere le dimensioni del pezzo inserite.

Una volta impostato il diametro dell'utensile nella apposita pagina della lavorazione 2D, viene proposto all'operatore il percorso utensile disegnato con un tratto blu. L'operatore deve eseguire un controllo visivo della correttezza del percorso utensile.

Tale controllo è necessario per verificare la correttezza del percorso nel caso in cui si siano verificati i casi limite di seguito elencati:

Percorso utensile che si chiude su se stesso:



This does not cause a tool compensation error.

Documento generato automaticamente da **Qem Wiki** - <https://wiki.qem.it/>

Il contenuto wiki è costantemente aggiornato dal team di sviluppo, è quindi possibile che la versione online contenga informazioni più recenti di questo documento.