

Sommario

MDO_P1P20F - 022 : Operator Manual	3
1. Informations	3
1.1 Release	3
1.1.1 Specifications	3
2. Description	4
3. Main page	5
3.1 Control bars and informations	5
3.2 Main Page 2	5
3.3 Main Page 3	6
3.4 Machine status	7
3.5 Common keys	7
4. Main menu	8
5. Utilization	9
5.1 Startup	9
5.2 Working program	10
5.2.1 Edit Workin Program	11
5.2.2 Sander machine parameters	12
5.2.3 Milling machine parameters	12
5.2.4 Grinding wheel parameters	13
5.2.5 Brush parameters	13
5.2.6 Water jet parameters	13
6. Work functions	14
6.1 Manual / Automatic	14
6.1.1 Manual	14
6.1.2 Automatic	16
6.2 Reset pezzi	16
6.2.1 Reset di tutti i pezzi	16
6.2.2 Reset di una selezione di pezzi	16
7. Diagnostica	18
7.1 Ingressi digitali	19
7.2 Uscite digitali	19
7.3 Conteggi	19
7.4 Uscite analogiche	20
7.5 Informazioni connessione CAN	20
7.6 Informazioni di sistema	21
8. Messaggi di warning	22
9. Allarmi	23
9.1 Storico allarmi	23
10. Assistenza	24
Riparazione	24
Spedizione	24

MDO_P1P20F - 022 : Operator Manual

1. Informations

1.1 Release


This document is valid except for errors or omissions.

			
Document:	mdo_p1p20fh20-001		
Description:	Manual Operator p1p20f-022		
Editor:	Omar Sbalchiero		
Approver	Gabriele Bazzi		
Link:	https://www.qem.eu/doku/doku.php/en/strumenti/qmoveplus/j1p20/p1p20f-022/mdo_p1p20f-022		
Language:	English		
Document release	Description	Note	Data
01	New manual		31/08/2021

1.1.1 Specifications

All rights reserved on this manual. No part of this document can be copied or reproduced in any form without prior written authorisation. QEM does not insure or guarantee its contents and explicitly declines all liability related to the guarantee of its suitability for any purpose. The information in this document can be changed without notice. QEM shall not be held liable for any error or omission in this document. QEM® is a registered trademark. Microsoft® and MS-DOS® are registered trademarks and Windows® is a trademark of Microsoft Corporation.

2. Description



The **P1P20F - 022** software, controls the automation of machines **sanders/edge-sanders**.


Main features

- control of **20 heads**
- control the **sequential start of motors** (to limit excessive power demand)
- can manages the **bridge movements**
- for each machining head, you can set **processing advances/delays** at the **beginning/end** of the piece
- the ascent/descent controls of the sanding heads, are calculated **automatically as the speed** of the conveyor belt change
- counts the **processed meters** and can work up to **30 pieces** simultaneously

Other features


- HMI with touchscreen
- Function keys
- Working program
- Alarm messages
- Warning messages
- Reset defective pieces
- Reset of all workpieces
- Compensation of the offset of the piece presence limit switch
- Mode of heads processing
 1. Smoothing
 2. Milling
 3. Grinding
 4. Brushing
 5. Water jet


3. Main page



3.1 Control bars and informations

The bars at the top and bottom of each page provide the following informations:




A	Machine status
B	Page name
C	Additional page description
D	Page number
E	Clock
F	Active alarm (red background)
G	Warning (azure background)
	Current conveyor belt speed
N:	Setting the conveyor belt speed
P:	Setting the bridge speed
	Bridge position. N.B. The position of the Bridge is enabled only if the encoder is present on the axis of the Bridge
	Machined linear meters
	Total number of pieces machined
	Number of parts currently being machined
	Last workpiece length

3.2 Main Page 2



Pressing the key , you can access the second main page:



In addition to the information on the main page, you can see:

- Heads status
- The current speeds of the conveyor belt and the bridge.
- N.B.** The the speed of the Bridge can be showed, only if the encoder is present on the axis of the Bridge
- The status of the part presence input



Pressing the key , for return to the main page.

3.3 Main Page 3



From the main page 2, pressing the key , you can access the third main page:



In addition to the information on the main page, are showed:

- The bridge speed and position.
- With the keys  and  you can to vary the back and forward limits of the Bridge.
- With the key  you can to start the search for homing of the Bridge



Pressing the key , you can return to the main page 2.

N.B. The Main Page "3" is enable only if is present the encoder on the Bridge axis.

• 3.4 Machine status

Symbols	Descriptions
	Manual
	Emergency
	Automatic
	Mode of operation
	Calibration
	Not initialized


3.5 Common keys

Symbol	Description
	Scroll through programs
	Save and exit: the setup values are saved in the internal memory and run
	open the program
	Forward page
	Backward page
	Exit without saving: the setup values entered are not saved and the values in the internal memory are reloaded.
	Access to the MENU page
	Access to the SETUP (protected with password)
	Access to the WORKING PROGRAMS
	Access to the TOTAL PIECES RESET
	Access to the PARTIAL PIECES RESET
	Access the the ALARMS
	Exit from the page

• 4. Main menu



For access from the **MAIN PAGE** press the key



	Alarms
	Access to programs
	Functions menu
	Diagnostics
	Bridge homing
	Access to the setup

• 5. Utilization

5.1 Startup

If the Bridge encoder is installed and enabled, when switched on, the instrument show the Main Page 3 and and it is requested to start the homing search to calibrate the position of the Bridge Axis.



Pressing the key  for start the homing search.

To the end of the homing search, the instrument show directly the Main Page.

• 5.2 Working program

For access to the "Working program" section:


1. press the **F3** function key 
2. or access the MENU page, pressing the **F1** key  than press the key 



To select one of the work programs listed, you must tap on the corresponding line.


 and 	To scroll through the list of work programmes. Each page can display 5 programs at a time. It is possible to move directly to the desired page by editing it on the title bar.
	Switching to the Work Cycle Editing Function.
	Opens the selected work program to edit it.

• 5.2.1 Edit Workin Program



Automatic program: execute the points **1 - 2 - 3 - 4** :


1. To change the program enter the values in the various fields, using the virtual **keyboard**.
2. Type on the field " UNIQUE VALUE" for copy the parameters of the first head on the all heads
3. Set machining parameters
4. After completing the parameter entry, pressing **F7** key and the **save the program** are show



Notes:

- 1 = **sander**, 2 = **milling machine**, 3 = **grind**, 4 = **brush**, 5 = **water jet**
- if the heads are **all of type 1 - 4 - 5**, or **all of the type 2**, or **all of the type 3**, you can set " **all heads** ", or " **single head** "
- if are set **mix of types 1 - 2 - 3** then the choice "single heas" are disable.

• 5.2.2 Sander machine parameters




By default the machining parameters are all at 0.

Parameter name	Units of measurement	Range	Description	
Advance(-)/Delay (+) head descent	mm	0 ÷ 99999.0	Advance or delay space	head descent from the beginning of the piece .
Advance(+)/Delay (-) head ascent	mm	0 ÷ 99999.0		head ascent from the end of the piece .

Polished piece only in the central part		Piece entirely polished	
Advance(+)/Delay (-) head ascent = +150	Advance(-)/Dealy (+) head descent = +300	Advance(+)/Dealy (-) head ascent = 000	Advance(-)/Delay (+) head descent = 000


5.2.3 Milling machine parameters




Parameter name	Units of measurement	Range	Description
99999999 Anticipo (-)	mm	0 ÷ 99999.0	Distance piece beginning / milling. It is the space between the beginning of the piece and the beginning of the milling process .
99999999 Anticipo (+)	mm	0 ÷ 99999.0	Distance piece ending / milling. It is the space between the end of the piece and the end of the milling working .
99999999 Lunghezza	mm	0 ÷ 99999.0	Milling length. It's the milling space.

NB: If one of the two distance parameters is greater than zero, the other is automatically set to -1 (parameter value disabled).

Milling with reference from begin of workpiece	Milling with reference from the end of the workpiece
---	---



5.2.4 Grinding wheel parameters



Parameter name	Units of measurement	Range	Description
99999999 Meters	mm	0 ÷ 99999.0	Worked linear meters. Space beyond which the grinding wheel wear compensation is activated.
99999999 Time	sec.	0 ÷ 99999.0	Head activation time. Activation time, the head performs a forward shift to compensate for the wear of the grinding wheel.

5.2.5 Brush parameters

The parameters are similar to the **sander** processing.

5.2.6 Water jet parameters

The parameters are similar to the **sander** processing.

• 6. Work functions

To select the desired work functions, press the key



	Manual/Automatic page
	* Start : Automatic machine start-up with heads rotation * Stop : Automatic machine start-up without heads rotation
	Go to the Piece Reset page

6.1 Manual / Automatic

To select the function of choosing the working mode, presse the key



The following page is showed:




	Operation mode selection MANUAL
	Operation mode selection AUTOMATIC

6.1.1 Manual

To select the MANUAL mode operation, press the key




The following page is Showed:



Description of possible operations in manual mode




Press the keys  and  you can move the conveyor belt.




Pressing the keys  and  it's possible to move the Bridge.

IN R
  -> Back Limit Switch and Back Slowdown.
R AU
  -> Slowdown Forward and Limit Switch Forward.
N.B. Bridge jog (MP-04 = 1)



Selection of the Head to be moved
N.B. In manual it is possible to move only one head at a time



Pressing the keys  and  it is possible to go up and descend the selected head

Pressing the keys  and  you can turn on/off the spindle rotation of the selected head

• 6.1.2 Automatic



cambiare link immagini da italiano in inglese Per selezionare il modo di funzionamento AUTOMATICO,



premere il tasto


Lo strumento si porta alla visualizzazione della Pagina Principale ed è pronto all'acquisizione dei pezzi in macchina.

6.2 Reset pezzi



Per selezionare il RESET dei pezzi , premere il tasto

Viene visualizzata la seguente pagina:



6.2.1 Reset di tutti i pezzi



Per selezionare il RESET dei pezzi , premere il tasto

Viene visualizzata la seguente pagina:




6.2.2 Reset di una selezione di pezzi



Per selezionare il RESET di una selezione di pezzi , premere il tasto

Viene visualizzata la seguente pagina:





Premere il tasto per selezionare i pezzi presenti nelle teste oltre la nr. 08.




Selezionare il/i pezzo/i che si intende/ono cancellare.



Premere il tasto

Viene visualizzata la seguente pagina.




Premere il tasto , per azzerare il/i pezzo/i da cancellare.


Nota

attendere che il Reset sia completato.

• 7. Diagnostica



Per accedere alla diagnostica, dalla pagina di **MENU** premere il tasto




Da questa pagina è possibile accedere alle varie sezioni di diagnostica presenti:

	Ingressi digitali
	Uscite digitali
	Conteggi
	Ingressi/uscite analogiche
	Informazioni connessione CAN
	Informazioni di sistema




Per tornare al **MENU** premere il tasto

• 7.1 Ingressi digitali



Per accedere alla pagina di diagnostica degli **Ingressi Digitali**, premere il tasto




Per tornare al menù di **DIAGNOSTICA** premere il tasto

7.2 Uscite digitali




Per accedere alla pagina di diagnostica delle **Uscite Digitali** premere il tasto




Per tornare al menù di **DIAGNOSTICA** premere il tasto

7.3 Conteggi



Per accedere alla pagina di diagnostica dei **Conteggi**, premere il tasto






Per tornare al menù di **DIAGNOSTICA** premere il tasto

7.4 Uscite analogiche



Per accedere alla pagina di Diagnostica delle **Uscite analogiche**, premere il tasto



L'uscita analogica è espressa in Volt.




Per tornare al menù di **DIAGNOSTICA** premere il tasto

7.5 Informazioni connessione CAN



Per accedere alla pagina di diagnostica della **Connessione CanOpen**, premere il tasto




Per tornare al menù di **DIAGNOSTICA** premere il tasto

• 7.6 Informazioni di sistema



Per accedere alla pagina di diagnostica delle **“Informazioni del sistema”**, premere il tasto



Fw name	firmware e checksum
Aux fw	firmware del modulo I/O
Task time	tempo ciclo CPU : Minimo, Medio, Massimo
CPU time	tempo CPU nello stato di Run (hh:mm)
Touch screen	Test touch



Per tornare al menù di **DIAGNOSTICA** premere il tasto

• 8. Messaggi di warning

Messaggio	Descrizione
Troppi pezzi in macchina	In macchina ci sono più di 30 pezzi
Attesa attivazione ausiliari...	Attesa abilitazione ausiliari (con <i>MP-08</i> abilitato)(I4 = ON)
Posizionamento quota cambio abrasivo...	Il ponte viene comandato nella posizione di cambio abrasivo
Ausiliari disabilitati	Ausiliari disabilitati (I4 = OFF)
Attenzione!!! Motori spenti.	Tentativo di Start nastro con motori spenti

• 9. Allarmi



Per accedere alla pagina della visualizzazione degli **ALLARMI**, premere il tasto



Premere il pulsante per cancellare l'allarme

Messaggio	Causa	Ingresso
Emergenza premuta	Controllare la linea dell'emergenza	I01
Fault Inverter	Controllare inverter	I12
Rottura encoder nastro	Controllare encoder nastro trasportatore (Attivo solo con <i>MP-03</i> > 2).	
Protezioni termiche	Controllare le protezioni termiche	I06
Carter	Controllare le protezioni perimetrali	I07
Mancanza aria	Controllare il pressostato	I08



Il messaggio "**Rottura encoder nastro**" viene generato automaticamente, se entro 5 secondi non è stato compiuto uno spazio superiore a 2 unità di misura in altre parole, il messaggio viene generato se lo strumento rileva una velocità inferiore a 60mm al minuto

9.1 Storico allarmi



Per accedere, dalla pagina di **ALLARMI** premere il tasto



Dopo aver **rimosso le cause** che provocano l'allarme, premere (x 3 sec.) il tasto per cancellare



Massimo 60 allarmi.

• 10. Assistenza

Per poterti fornire un servizio rapido, al minimo costo, abbiamo bisogno del tuo aiuto.

	
Segui tutte le istruzioni fornite nel manuale MIMAT	Se il problema persiste, compila il “Modulo richiesta assistenza” nella pagina Contatti del sito www.qem.it. I nostri tecnici otterranno gli elementi essenziali per comprendere il tuo problema.

Riparazione

Per poterVi fornire un servizio efficiente, Vi preghiamo di leggere e attenerVi alle indicazioni qui [riportate](#)

Spedizione

Si consiglia di imballare lo strumento con materiali in grado di assorbire eventuali cadute.

		
Utilizzare l'imballo originale: deve proteggere lo strumento durante il trasporto.	Allega: 1. Una descrizione dell'anomalia; 2. Parte dello schema elettrico in cui è inserito lo strumento 3. Programmazione dello strumento (setup, quote di lavoro, parametri...).	Una descrizione approfondita del problema ci consentirà di identificare e risolvere rapidamente il tuo problema. Un accurato imballaggio eviterà ulteriori inconvenienti.

Documento generato automaticamente da **Qem Wiki** - <https://wiki.qem.it/>

Il contenuto wiki è costantemente aggiornato dal team di sviluppo, è quindi possibile che la versione online contenga informazioni più recenti di questo documento.