


Índice

MDO_P1P44F-010: Operator Manual	3
1. Informations	4
1.1 Release	4
1.1.1 Specifications/Copyright	4
2. General features	5
2.1 Description	5
2.2 Workings	5
2.3 Options	5
2.4 Features	5
2.5 Executable working	5
3. Hardware	7
3.1 Function and LED keys	10
3.2 Symbols and keys	10
3.3 Startup	11
4. Main menu	12
5. Homing	14
5.1 Homing procedure	14
5.2 Error Delta	15
6. Machine datas	16
7. Bottom bar	17
8. Manual/Semi-Automatic	18
8.1 Semi-Automatic Execution	22
9. Reset axes	23
10. Restart working	24
11. Multiple Cuts/Automatic	25
11.0.1 Without table rotation	26
11.0.2 With table rotation	26
11.0.3 Axes parameters	27
11.0.4 Working parameters	29
12. Tilted Cuts/Automatic	30
12.0.1 Working parameters	33
13. Flattening	34
13.0.1 Working parameters	36
13.0.2 Axes parameters	36
13.0.3 Working parameters	36
14. Programming and executing profiles	37
14.1 Program list filtering	38
14.2 Profiles	39
14.2.1 Profiles - CAD	40
14.2.2 Profiles - parameters	44
15. Execution	46
15.1 Program execution	46
15.1.1 Profile execution	48
15.1.2 Axis parameters	48
15.1.3 Working parameters	49
16. Alarms	50
16.1 Alarms list	51
16.2 Messages	51

17. Diagnostic	52
17.1 CPU DATA	53
17.2 Digital inputs	54
17.3 Digital outputs	54
17.4 Encoder counters	54
17.5 Analog outputs	55
17.6 Analog inputs	55
17.7 Communication with RMC1S modules	55
18. Assistance	56
Repair	56
Shipping	56

MDO_P1P44F-010: Operator Manual

1. Informations

1.1 Release

			
Document:	mdo_p1p44f-010		
Description:	p1p44f-010 Operator Guide		
Editor:	Michele Sandri		
Approver	Gabriele Bazzi		
Link:	http://www.qem.eu/doku/doku.php/en/strumenti/qmoveplus/j1p44/p1p44f-010/mdo_p1p44f-010		
Language:	English		
Document Release	Description	Note	Data
01	New Manual		27/08/2019
02	Add Description and Y-Axis Calculation Function Page		31/03/2021

1.1.1 Specifications/Copyright

The copyright of this manual is reserved. No part of this document can be copied or reproduced in any form without the prior written permission of the QEM.

QEM has no assurances or guarantees on the content and specifically disclaims any liability inherent in the guarantees of eligibility for any particular purpose. The information in this document is subject to change without notice. QEM does not take any responsibility for any errors that may appear in this document.

Trademarks:

- QEM® is a registered trademark.

2. General features

2.1 Description

The J1-P44-FB20 instrument with the P1P44F-010 software, it's suitable for automating a machine type: **“cutter for stone processing”**.

2.2 Workings

- single cut
- tile cutting
- tilt cut ¹⁾
- profiling
- drawing profiles with Mini Cad inside
- profile drawings with Cad on PC and importing on the instrument with “ Profile Importer 8” program with USB or LAN key
- table flattening

¹⁾ with parameters, you can define whether the inclined cut will be done with the tilt of the beam, or with the tilt of the disk

2.3 Options

- the W table can be motorized or manual
- the H-axis may or may not be there, if present it can be manual or motorized or only mechanical (without encoder)

2.4 Features


- The axes can be controlled with:
 - normal positioning
 - with the conclusion of the positioning with “pulse technique”, which allows you to achieve greater accuracy, if mechanical inertia tended to make the positioning wrong.
If due to the mechanics and type of inverter, the final part of the positioning was incorrect, the tool to overcome this problem, provides this functionality.
Typically, it is used on the Table or W-axis, on which very different weights can be loaded between them...causing a NOT constant space of inertia .
- Bridge lifting alarm: If the Z-axis were to happen, pressing down would lift the bridge, the limit switch installed on the bridge and connected to the I67 input will activate the alarm.
- Manage of X Y Z + W (Table rotation) axes + H (disk tilt).



The H encoder is connected to the J1-P44-FB20 instrument, while the X Y Z-W encoders are connected to the RMC1S modules


- Errors in the mechanics of the W and H axes can be corrected by providing no.8 linearization sectors.
- There is a table in which you can set the maximum diameter and turns of the cutting disk.
- Measuring and displaying the current of the cutting disc; the maximum current setting is allowed.


2.5 Executable working




 Profiling	 Flattening	
--	---	--

■ 3. Hardware







• 3.1 Function and LED keys

Key	Icon	Function	Led	Key	Icon	Function	Led
F1		Start Cycle	-	F4		Semi-automatic = ON	Active semi-automatic
F2		Stop Cycle	-	F5		Alarm = ON	Alarm
F3		Restart	-	F6		Exit	-
----	----	----	----	----	----	----	----

3.2 Symbols and keys


Key	Description	-----	Top bar symbols	Description
	Press to confirm			Initialization
	Selection			Emergency
	Previous page			Manual
	Next page			Homing active
	Reserved area			Semi-automatic
	Open file from USB			Automatic - cycle OFF
	Save			Automatic - cycle ON
	Working preview			Calibration mode
				Protected/Unprotected Setup
	The yellow data is editable			


• 3.3 Startup

START		The instrument waiting the input to be activated “activated auxiliaries”¹⁾ to automatically go to the next page Important: pressing the button   you can navigate the HMI, with the machine stationary
HOMING		OR  F6 for exit
MAIN MENU		

¹⁾ These are the 24 Volt dc power supplies of the RMC1S modules, limit switches, encoders, relays, etc.

• 4. Main menu





• 5.2 Error Delta


This data indicates the **Error Delta compared to previous homing**, with this value you can easily check if an encoder is good or is broken.

Procedure:

1. Execute an homing ¹⁾
2. Move the axis in manual, numerous times forward and backward
3. Then, without turning off the machine, re-execute the homing
4. The second homing will make it take on an **“important”** meaning to this number: will show us how much is the offset of the count compared to the actual physical position of the machine
5. If the encoder counts well, this offset must be = 0
6. Then, in practice, this number probably won't always be just = 0 due to the tolerance of limit switch used to do homing
7. Repeating the homing several times, you will be able to realize if the number shows a faulty encoder, or an error given by the tolerance of the limit switch
8. A small error not always repetitive, evidence the tolerance of the limit switch
9. A big error, it will show clearly, a problem to the encoder

¹⁾ The first time you execute an homing (after the instrument is turned on), this number doesn't have a utility

• 6. Machine datas



Setting Minimum location Z 	Automatic setting Minimum location Z 	SECURITY QUOTE setting
 Disk RPM	 Disk diameter	 Diameter and RPM setting
 Current Disk Absorption	 AL : Maximum current setting WR : Early warning threshold setting	 Disk thickness setting
 Out-of-clutter position	 Parking position	 Tool change position
DISK DIAMETER AND RPM		
 Disk diameter	 Marble	 Granite
 Automatic RPMs based on disk diameter - Setting an RPM Override		

• 7. Bottom bar




	: Active Stateflow Alarm : Off Stateflow Alarm	
	: EV water deactivates : EV active water	
		Ø : Current diameter RPM : Set the desired rounds MIN RPM : Minimum setable value MAX RPM : Maximum setable value
99999 A	Instantaneous absorption of spindle current.	If the WRN symbol appears above the current absorption indication, it means that the pre-alarm threshold has been exceeded.
	: EV laser disables : EV laser active	



• 8. Manual/Semi-Automatic


The diagram illustrates the sequence of screen transitions for Manual/Semi-Automatic operation:

- MAIN MENU:** The initial screen showing various function icons. A hand icon points to the **F6** button, which leads to the next screen.
- MANUAL:** The screen displays the **BASE** mode and various axis parameters (X, Y, Z) with their respective positions and speeds. A hand icon points to the **X** axis selection button.
- X AXIS:** The screen displays the **X** axis parameters and a **RESET REL. POSIT** button. A hand icon points to the **Y** axis selection button.
- Y AXIS:** The screen displays the **Y** axis parameters and a **RESET REL. POSIT** button. A hand icon points to the **Z** axis selection button.
- Z AXIS:** The screen displays the **Z** axis parameters and a **RESET REL. POSIT** button. A hand icon points to the **W** axis selection button.
- W AXIS:** The screen displays the **W** axis parameters and a **RESET REL. POSIT** button. A hand icon points to the **H** axis selection button.
- H AXIS:** The screen displays the **H** axis parameters and a **RESET REL. POSIT** button. A hand icon points to the **SINGLE CUT** button.
- SINGLE CUT:** The screen displays the **SINGLE CUT** mode and various parameters (X, Y, Z, W, H) with their respective positions and speeds. A hand icon points to the **SPINDLE RPM** button.



TARGET POSITION SET	ABSOLUTE TARGET POSITION INCREMENTAL TARGET POSITION 0 TARGET POSITION	Reset Relative Position
	Disk Compensation OFF ON	

		Minimum Z Position  Z Minimum Position Self-Learning 
		
		
		
 X positions self-learning	 X START Cut Position	 X END Cut position
 Single Pass	 Greek cutting	 Cut Depth

Set dati del taglio a greca (max 10)   01		% Reducing the speed of the first cut		
		Forward lowered (X+)		Backward lowered (X-)
Last Cut Direction 		Last lowered depth		% Reducing the speed of the last cut


• 8.1 Semi-Automatic Execution

1. Check that you are in manual 
2.  **F4** → 
3.  external **START** key (I10) or **F1**
4. the axis reaches the set dimension or single-cut is executed.

• 9. Reset axes

The reset axes function **reset RELATIVE quotas**

1. Check you're in manual mode



1. **X** - : hold to reset the X-axis count

2. **Y** - : hold to reset the Y-axis count


3. **Z** - : hold to reset the Z-axis count

4. **F6** - Exit from the page

• 10. Restart working



The restart function **restarts the loaded working from the beginning**



1. Check that you're in manual mode 
2. Check that you're on one of the work pages




1. **OK** -  : press to confirm the restart and exit the page
2. **F6** - Exit from the page without confirmation

• 11. Multiple Cuts/Automatic


	
	
	
	
	




Z



Input data set



Last Cut Direction

Forward lowered
(X+)Backward lowered
(X-)

Last Cut Depth







% Reducing last
cut speed**First cut**

% Reducing first cut speed
Position of first increment of passes cut.

Advance





Space before FC software X when Z begins the lowered





• 11.0.4 Working parameters

		
Y DIRECTION	POSITIVE The piece thickness is made with Y that increment 	NEGATIVE The piece thickness is made with Y that decrements 
CUT DIRECTION	X+ Forward only 	BILATERAL to greek 
CUT TYPE	SINGLE one pass 	TO LOWERED multi-pass 
Z LIFT	Z lift when X is in the FORWARD POSITION 	X and Z come out TOGETHER from the slab 
END CYCLE	The axes STOPPED when the cycle is end 	The disk goes to PARKING at the end of the cycle 
XY	 X and Y axes in parking one after another	 X and Y axes in the parking lot at the same time
ROTATION	WITHOUT TABLE ROTATION 	WITH TABLE ROTATION 





- **12. Tilted Cuts/Automatic**





	
	
	
	
	
H axis without ENCODER	

		1 Current positions and axis target dimensions 2 Current work step 3 Size of the cut (Y) 4 Number of cuts to be execute 5 Pieces counter 6 Cuts list scroll (1-10) 7 Working parameters 8 Cutting Depth (Z) 9 Settable cut angle (I)
	Axes parameters - see Multiple Cuts	
H axis with ENCODER		
		1 Current positions and axis target dimensions 2 Current work step 3 Size of the cut (Y) 4 Number of cuts to be execute 5 Pieces counter 6 Cuts list scroll (1-10) 7 Working parameters 8 Cutting Depth (Z) 9 Settable cut angle (I)
	Axes parameters - see Multiple Cuts	



• 12.0.1 Working parameters

		
Y DIRECTION	POSITIVE The piece thickness is made with Y that increment 	NEGATIVE The piece thickness is made with Y that decrements 
CUT DIRECTION	X+ Forward only 	BILATERAL to greek 
WIDTH TYPE	90° thickness compared to the cut 	PARALLEL thickness to the surface of the plate 
DEPTH TYPE	Depth = along the disk 	Depthà = 90° relative to the surface of the plate 
END CYCLE	The axes STOPPED when the cycle is end 	The disk goes to PARKING at the end of the cycle 
XY	 X and Y axes in parking one after another	 X and Y axes in the parking lot at the same time



• 13. Flattening





• 13.0.1 Working parameters

Y width	Total width of the part to be flattened.
Y step	The value of the pitch that covers the Y axis after each cut.
Z depth 	Cut Depth. Used if lowered cut is set.
Z step 	The value of the step that covers the Z axis with each pass. Used if lowered cut is set.


13.0.2 Axes parameters

	
	 Self-learning positions X1 + X2 = Software limit switch of cutting N.B. the disc must exit the slab before learning the X1 - X2 dimensions

13.0.3 Working parameters

CUT TYPE	SINGLE one pass 	TO LOWERED multi-pass 
	X+ Forward only 	BILATERAL to greek 
CUT DIRECTION		
Y DIRECTION	POSITIVE The move of Y takes place in the positive direction 	NEGATIVE The move of Y takes place in the negative direction 
END CYCLE	The axes STOPPED when the cycle is end 	The disk goes to PARKING at the end of the cycle 

14. Programming and executing profiles



14.1 Program list filtering



Using the program list filter you can quickly view the desired program, without scrolling through the entire list. The system has two types of filtering that can be combined together:


- Program Description Filter
- Program Type Filter

What's a “**Program type**” :



Type	Description
0	Show all programs
1	Show profiling programs only
2	Show milling programs only Not enabled in this version
3	Show cutting polygons programs only Not enabled in this version



• 14.2 Profiles















			 	 
			 	 

14.2.1 Profiles - CAD



								
		Repeat Shape		Mirror Shape	Z0 = origin Y Coordinate = 0			
		Zoom in		Zoom out		Fit to screen		
	 000 		Scroll to choose the stroke you want					
		Add a stroke		Insert a stroke		Delete a stroke		Stroke properties









									
Stroke types									
	Absolute final coordinates are absolute relative to the origin					Incremental final coordinates are relative to the end of the previous stroke			
--	--	--	--	--	--	--	--	--	--

		Insert final coordinates
		 Insert Y coordinate  Insert Z coordinate  Insert L = length
		Enter the end coordinates and radius MINIMUM it's the least radius possible   clockwise   anticlockwise Choosing the direction of the curve  clockwise  anticlockwise clockwise OR anticlockwise  short arc  long arc The program shows the lowest possible radius value

ARC FOR 3 POINTS 		Insert the coordinates of the endpoint and midpoint 
TANGENT ARC 		Insert the coordinates of the endpoint 
TRANSFER 		Stroke movement without cuts. Enter end point coordinates 
		The software automatically corrects the undercut set.


- 14.2.2 Profiles - parameters




Size of the solid. As an option, you can enter the size of the solid. This will be grayed out in the CAD pages of working preview. 	Over Material on the profile SM= 999999 		Cutting direction only to X+  Bilateral cut 	Y-axis increment direction  
Distribution of cuts  D= 99999 B.W. 99999	Strategy type D= 99999	Disk thickness B.W. 99999	Preview cuts 	 Distribution along the Y-axis OFF: notable points are not processed 
	 Distribution along the profile 	 Distribution along the Y-axis ON: Guaranteed cut on important points 		
Working repetition  NP= 999 SP= 9999999		NP = Number of repetitions SP = Space between repetitions		

• 15. Execution

15.1 Program execution

	
	
	Choose and select the program to preview 
	
	



15.1.1 Profile execution

	1 Current positions and axis target dimensions 2 Running shape 3 Working parameters 4 Preview of the drawn shape
--	--

15.1.2 Axis parameters


	Self-learning of X1 + X2 positions = Software limit switch of cutting		
	Input lowered data set	0 ~ 10	Last cut direction
	Forward lowered (X+)		Backward lowered (X-)
	Last Cut Depth		% Reducing last cut speed
First Cut % Reducing first cut speed			
Advance Space before FC software X when Z begins the lowered			

• 15.1.3 Working parameters

CUT TYPE	SINGLE one pass 	TO LOWERED multi-pass 	
END CYCLE	The axes STOPPED when the cycle is end 	The disk goes to PARKING at the end of the cycle 	
	The following symbols are view-only They are programmed in the appropriate parameter pages.		
Y DIRECTION	POSITIVE The next cut is done with Y that increments 	NEGATIVE The next cut is made with Y that decrements 	
CUT DIRECTION	X+ Forward only 	BILATERAL to greek 	
STRATEGY	CUTS ALONG THE PROFILE 	CUTS ALONG Y - Notable ON 	CUTS ALONG Y - Notable OFF 

At the push of the **START CYCLE** key, the machine starts with the working set.

• 16. Alarms



The alarms block all machine operations.

Alarm	Cause	Solution
Emergency	Stop for emergency switch	-
Y axis limit switch FW	The Y-axis has encountered the forward limit switch	-
Y axis limit switch BW	The Y-axis has encountered the backward limit switch	-
Z axis limit switch UP	The Z-axis has encountered the up limit switch	-
Z axis limit switch DOWN	The Z-axis has encountered the down limit switch	-
X axis limit switch FW	The X-axis has encountered the forward limit switch	-
X axis limit switch BW	The X-axis has encountered the backward limit switch	-
H axis limit switch FW	The H-axis has encountered the forward limit switch	-
H axis limit switch BW	The H-axis has encountered the backward limit switch	-
Tool not running	The disk must be moving during the automatic cycle	-
No water pressure	Missing of cooling water	Control the water flowstate
Mandrel motor overcurrent	The absorption of the motor disk is over the alarm threshold	-
No oli pressure	Missing of pressure in the lubrication circuit	Check the oil flowstate
X encoder fault	Failure to detect counter	Check the encoder
Y encoder fault		
Z encoder fault		
W encoder fault		
H encoder fault		
Thermal outout tripped	A thermal drive has been activated	-
Fault inverters	Fault of the axes inverter	-
Spindle inverter fault	Fault of the spindle inverter	-
CAN module disconnected	The remote module does not communicate	Check the settings and the cable
CAN2 module disconnected		
X axis out of tolerance	Positioning ended out of tolerance	Check the axis parameters
Y axis out of tolerance		
Z axis out of tolerance		
W axis out of tolerance		
H axis out of tolerance		
Safety enclosure alarm	Perimeter safety protection barriers have been opened	-
No air pressure	Missing of pressure in the air circuit	Check the air flowstate
Wait for power system...	Inactive auxiliary inputs. Communication interrupted with the 2nd RMC15 module at input I74.	Activate auxiliary inputs. Check communication with the 2nd RMC15 module.
No power system	Machine auxiliaries are deactivated	-
Inverter generic fault	Inverters have a non-resetable error	Contact the manufacturer of the inverter
Bride out of guides	Reports that the bridge has lift and the I79 limit switch has intervened.	Reset the alarm and bring the bridge back to the binars

• 16.1 Alarms list






to clear the alarms list


16.2 Messages

The messages do not block machine operations.

Message	Cause	Solution
PLEASE WAIT...	Data is being processed	-
PATH ERROR	Error calculating axis path	The tool is too wide
ERR: TILTED DISK	Disk tilt is not compatible with the current working	Correct tilt
X OVER MAX LIMIT	The target dimension of the axis is over the maximum limit switch	-
Y OVER MAX LIMIT		-
Z OVER MAX LIMIT		-
X OVER MIN LIMIT	The target dimension of the axis is over the minimum limit switch	-
Y OVER MIN LIMIT		-
Z OVER MIN LIMIT		-
WORK DONE	The automatic cycle has successfully ended	-
X POSITION NOT OK	The X position is incorrect	The position of X is inside the software limit switches
RUN HOMING	Homing was not executed	Run the procedure
NO OBJECT	You try to open a non-existent geometry	-
WAIT FOR START...	The working waits for the START command	-
COMPENSATION ERROR	Error calculating disk compensation	Check the shape design
POWER TOOL ON	Start the disk to start the cycle	-
Y OVER MAX/MIN LIMIT	Processing data requires a Y movement beyond software limits	-
BRIDGE OUT OF RAIL	The bridge is lifted	See Alarm Reporting Description

• 17. Diagnostic


	
	
	 
	 
	   



17.1 CPU DATA

<pre> CPU DATA Fw name: AAAA-99.9.99 (Fw check.:999999999999 dec) Task time: 99999ms Max task time: 99999ms Min task time: 99999ms CPU time: 99999:99 </pre>	Fw name : firmware code and checksum Task time : average time of CPU cycle Maximum Time and Minimum Time registered limits CPU time : total CPU time in RUN state (hh:mm)
---	--

• 17.2 Digital inputs

 INPUTS 		Status of digital inputs  = OFF  = ON
	Previous page	
	Next page	


17.3 Digital outputs

 OUTPUTS 		Status of digital outputs  = OFF  = ON
	Previous page	
	Next page	
	Press to switch to output force mode Press the output that you want to activate.	


17.4 Encoder counters

 COUNTERS 		Axes position  = OFF  = ON
---	---	--


• 17.5 Analog outputs



17.6 Analog inputs



17.7 Communication with RMC1S modules



• 18. Assistance

For supplying you fast service, at the lowest cost, we need your support.

	
Follow all instructions provided in the MIMAT manual	If the problem remains, fill out the “Request Form for assistance” on the page Contacts at www.qem.it site. Our technicians will get elements essential for the understanding of your problem.

Repair

To provide you with an efficient service, please read and adhere to the instructions given [here](#)

Shipping

It is recommended to pack the instrument with materials that are able to cushion any falls.

		
Use the original package: it must protect the instrument during transport.	Attach: 1. A description of the anomaly; 2. A part of the electric scheme where the equipment is inserted 3. The planning of the equipment (set up, quotas of job, parameters...). 4. Request a quote for repair; if not required, the cost will be calculated in the final balance.	A full description of the problem, will help identify and resolve your problems fast. A careful packaging will avoid further inconveniences.

Documento generato automaticamente da **Qem Wiki** - <https://wiki.qem.it/>

Il contenuto wiki è costantemente aggiornato dal team di sviluppo, è quindi possibile che la versione online contenga informazioni più recenti di questo documento.