

目录

WHP001 - Firmware Update procedure	3
1. Informations	3
1.1 Specifications	3
1.2 Validity	3
2. Warnings	3
3. Bootloader and Boot state	3
4. MMC/SD memory use	3
5. Firmware Downloader Utility	4
5.1 CPU Info	4
5.2 Go BOOT	5
6. Error messages	6
6.1 Bootloader error codes	6
7. Connecting Accessories	6
8. Note	6

WHP001 - Firmware Update procedure

1. Informations

1.1 Specifications

The copyright to this manual are reserved. For no reason, this document may be copied or reproduced in any form without the QEM permission.

QEM has no assurances or warranties regarding to content. Qem disclaims any responsibility relating to warranties of fitness for any particular purpose. The informations in this document are subject to change without notice. QEM not assumes responsibility for any error that may appear in this document

Trademarks :

- QEM® is a registered trademark.
- Microsoft® and MS-DOS® ar registered trademarks of Windows® and it is a trademark of the Microsoft Corporation.

1.2 Validity

This document is valid in full except for errors or omissions.

Document Release	Description	Date of issue
0	New document	21/12/2010
1	Update to build 1.0.11 recompiled with Bundlesuite-3 package	14/03/2011
2	Wiki version	08/11/2013
3	Added indications for I/O module products RMC and the notes section	29/11/2013

2. Warnings

The firmware update operation allows you to add new features nd to fix any problems encountered in previous versions. Then make sure before proceeding, to have understood all the steps of the procedure and to have all the necessary tools.



ATTENTION: The firmware upgrade operation is particularly dangerous if it does not execute properly. May damage the instrument.

3. Bootloader and Boot state

The **Bootloader** s a particular program that is execute by the instrument when it is switched on and allows you to upgrade the firmware.

When the bootloader is active, this means that the instrument is in [Boot State](#) or [Boot Mode](#). The Boot Mode state is indicated by the power on of **STOP led** (or **BOOT/L1** led In the case of a type I/O module [RMC](#)).

To place the instrument in Boot Mode simply turn it on by pressing and holding the **BOOT button** until the STOP led (or BOOT/L1) remains on steady.

4. MMC/SD memory use

Qem instruments normally have the firmware upgrade feature using an MMC/SD card (Multi Media Card / Secure Digital). On these instruments the bootloader can handle the firmware upgrade procedure automatically if in the power on detects in the MMC/SD memory, a file named "**firmware.a21**".

It's necessary:

1. Receive from Qem the file with the correct firmware.
2. You have an MMC/SD memory that is compatible with the instrument specifications.
3. Format MMC/SD memory with filesystem (FAT or FAT32) compatible with the instrument specifications.
4. Copy the file containing the firmware into the MMC/SD memory and then rename it to "**firmware.a21**".
5. Insert the MMC/SD memory in the instrument slot (attention to the insertion direction).
6. Turn on the instrument by holding down the boot button until the STOP led starts blinking.

7. At the end of the procedure, where the duration can be of few minutes, in the absence of errors the instrument will automatically start with the new firmware.




Updating the firmware using an MMC/SD isn't possible in the I/O module type **RMC** product.

5. Firmware Downloader Utility

The FirmwareDownloader utility, present in the [QWorkbench](#) package, allows you to execute the firmware update operations of a Qmove instrument, MicroQMove or I/O module type **RMC** via a serial connection between the PC and the PROG port of the instrument. To activate the utility, start the application as a link to the menu: Start ? Programs ? Qem ? Qworkbench 1.1 ? Utilities ? FirmwareDownloader-2 ? FirmwareDownloader20. All'attivazione l'utility si presenta con un'interfaccia a dimensione fissa. In the **Firmware FileName** box you must insert the path and name of the file that contains the firmware to download. You can use the "Browse..." button to select the file. In the **COM Port Number** box, insert the COM number to which the instrument is connected. Values from 1 to 99 are admitted.

With the tool in Boot Mode you can then start the firmware update procedure pressing the "START" button.




All messages, including any errors, appear in the notification area. If the procedure ends correctly, will appear the "**Operation successfully**" message and the instrument will automatically start.

Also with the products Qmove+ and Microqmove (not with I/O modules type **RMC**) two other operations are possible: **CPU Info** and **Go BOOT**.

5.1 CPU Info


With the instrument on, connected and not in the **BOOT** state, you can execute a connection test by pressing the "CPU Info" button.



If the connection is correct, the speed data will be showed to the instrument where the port is configured, The CPU status and checksums for the QCL application.


5.2 Go BOOT

If the instrument is not in the BOOT state, pressing the “GO BOOT” button, You send a command to the CPU that puts it in **Boot Mode**.



6. Error messages

If the upgrade procedure does not end correctly an error code is generated. If you use the FirmwareDownloader software, it is showed in hexadecimal form as shown in the below image.



```
Transfer 0% Time elapsed: 0m 0s Time left: 10m 0s
ERROR during download at line 1
Target reply is:
err000B*
```

If you are using the load from MMC/SD the error is showed by flashing the **led ERROR**. The number of flashes indicates the decimal error code.

6.1 Bootloader error codes

In the following table shows the possible error codes:

Hexadecimal error code	Number of ERROR led flashes	Error description	Restore operation
0x0001	1	BE_CHECKSUM: error Transferring file.	Retry the transfer
0x0002	2	BE_CRYPT: decoding error.	Verify that the file you want to transfer is correct for the instrument Retry the transfer
0x0003	3	BE_OUTMEMORYSIZE: memory error.	Retry the transfer
0x0004	4	BE_RECEIVE: error Transferring file.	Retry the transfer
0x0005	5	BE_RECEIVE_DWLN: error Transferring file.	Retry the transfer
0x0006	6	BE_PARITY: error Transferring file.	Retry the transfer
0x0007	7	BE_FORMAT_0: error Transferring file.	Retry the transfer
0x0008	8	BE_FORMAT_1: error Transferring file.	Retry the transfer
0x0009	9	BE_DECODE: error Transferring file.	Retry the transfer
0x000A	10	BE_IDFWSAVE: storage error.	Retry the transfer
0x000B	11	BE_IDHARDWARE: incorrect file.	Verify that the file you want to transfer is correct for the instrument Retry the transfer
0x000C	12	BE_USERVALUE: failed verification.	Verify that the file you want to transfer is correct for the instrument Retry the transfer
0x000D	13	n.d.	
0x000E	14	BE_FLASH: flash storage Error.	Retry the transfer
0x000F	15	BE_PROGPLD: PLD Component Storage Error.	Verify that the file you want to transfer is correct for the instrument Retry the transfer
0x0010	16	BE_FWNOPRESENT: firmware Storage Error.	Retry the transfer
0x0011	17	BE_UNKNOWN: unknown error.	Retry the transfer

7. Connecting Accessories

In order to use the Firmware Downloader utility it is necessary to establish a serial connection between the PC where the utility is installed and the instrument to be programmed.

If your PC has a RS232 serial port, you can use the [IQ013 - Kit opto-insulated serial interface RS232→TTL-3V3](#) accessory.

If your PC has a USB interface, you can use the [IQ009 - USB→RS232/TTL-5V interface kit](#). accessory.

8. Note

If you are using the iq009 link interface there have been problems with the **driver USB version 2.8.28**.

Problems are most evident when you update the firmware of a product Series 2, Series 5, some MicroQmove and the I/O modules type [RMC](#). It's necessary to update the drivers to the latest version. The drivers are available at <http://www.ftdichip.com/Drivers/VCP.htm> or in the Package installation folder [QWorkbench](#) typically at the C:\Programmi\Qem\Qworkbench11\utilities\iq009files\drivers location.

Documento generato automaticamente da **Qem Wiki** - <https://wiki.qem.it/>

Il contenuto wiki è costantemente aggiornato dal team di sviluppo, è quindi possibile che la versione online contenga informazioni più recenti di questo documento.