

**Sommario**

|                                        |          |
|----------------------------------------|----------|
| <b>ST10atoi .....</b>                  | <b>3</b> |
| <b>    <i>IMPLEMENTATION</i> .....</b> | <b>3</b> |



## ST10atoi

**ST** = *String functions*

The ST10atoi() function takes a string (which represents an integer) as an argument and returns its value of type int. Like atoi() in c language but with source\_start to point to a source string position.

## IMPLEMENTATION

**ST10atoi(source, source\_start, return)**

Parameters:

| IN/OUT | VARIABLE TYPE | EXAMPLE NAME | DIM |
|--------|---------------|--------------|-----|
| IN     | ARRGBL        | source       | B   |
| IN     | GLOBAL/CONST  | source_start | L   |
| IN     | GLOBAL        | return       | L   |

Documento generato automaticamente da **Qem Wiki** - <https://wiki.qem.it/>

Il contenuto wiki è costantemente aggiornato dal team di sviluppo, è quindi possibile che la versione online contenga informazioni più recenti di questo documento.