

Sommario

Connector

@cnn@	Terminal	Simbol	Description			Address
			Potentiometric / 0-10V / 0-20mA	Termocouple	PT100	
	1	GAI	Analog inputs common	-	-	
	2	VREF	Reference volatege ¹⁾	-	-	
	3	AI1_A	Analog input 1	-	A ²⁾	@slot@.AI01
	4	AI1_B	-	TC 1 -	B	
	5	AI1_C	-	TC 1 +	C	
	6	AI2_A	Analog input 2	-	A ³⁾	@slot@.AI02
	7	AI2_B	-	TC 2 -	B	
	8	AI2_C	-	TC 2 +	C	

¹⁾ For potentiometric inputs

^{2), 3)} A and B cables connected to the resistance, have the same color.

In the case of 2-wire PT100 you must make a jumper between A and B.

Analog inputs setting

	Num. Dip	Analog input 1					Analog input 2				
		PT100	Termocouple	Pot.	0-10V	0-20mA	PT100	Termocouple	Pot.	0-10V	0-20mA
 OFF ↔ ON	1	ON	X	OFF	OFF	OFF	X	X	X	X	X
	2	OFF	X	ON	ON	ON	X ¹⁾	X	X	X	X
	3	X	X	X	X	X	ON	X	OFF	OFF	OFF
	4	X ²⁾	X	X	X	X	OFF	X	ON	ON	ON
	5	ON	ON	OFF	OFF	OFF	X	X	X	X	X
	6	OFF	OFF	ON	ON	ON	X	X	X	X	X
	7	OFF	ON	X	X	X	X	X	X	X	X
	8	X	X	X	X	X	OFF	ON	X	X	X
 OFF ↔ ON	1	X	X	X	X	X	X	X	OFF	OFF	ON
	2	X	X	X	X	X	X	X	OFF	ON	OFF
	3	X	X	OFF	OFF	ON	X	X	X	X	X
	4	X	X	OFF	ON	OFF	X	X	X	X	X

X = setting not significant

Pot. = potentiometric type input

¹⁾ To set OFF if not use for analog input 1

²⁾ To set OFF if not use for analog input 2

Documento generato automaticamente da **Qem Wiki** - <https://wiki.qem.it/>

Il contenuto wiki è costantemente aggiornato dal team di sviluppo, è quindi possibile che la versione online contenga informazioni più recenti di questo documento.