

Table of Contents

Firmware Upgrade

Upgrade the firmware of the instrument through the external storage device MMC/SD or USB.

In the external storage device MMC / SD or USB must be present the following file:

- **firmware.a21**

The procedure performs the following steps:

- Check the presence of the MMC / SD or USB.
- Firmware Update.
- Closing the file and end operation.
- Automatic restart of the instrument.

Documento generato automaticamente da **Qem Wiki** - <https://wiki.qem.it/>

Il contenuto wiki è costantemente aggiornato dal team di sviluppo, è quindi possibile che la versione online contenga informazioni più recenti di questo documento.