

Inhaltsverzeichnis

Set Ethernet communic. parameter

This views and modifies the communication parameters of the ETHERNET port.
When the function is accessed all data saved on the controller is shown.

SYSTEM FUNCTIONS 12 - Set Ethernet communic. parameter MAC address: E2-40-00:BC-5E-B2 IP address.: 192.168. 0.141 GateWay...: 0. 0. 0. 0 Net Mask...: 255.255.255. 0 Port nr. 1: 5001 Port nr. 2: 5002 Port nr. 3: 0 Port nr. 4: 0 Press BOOT or ENT to modify Press FUNC or F1 to EXIT	To change a parameter press ENTER and introduce the new setting. Press ENTER to go to and change the next box. When the last box is confirmed, the data is saved and the „saving data...“ message is given
--	--

Documento generato automaticamente da **Qem Wiki** - <https://wiki.qem.it/>

Il contenuto wiki è costantemente aggiornato dal team di sviluppo, è quindi possibile che la versione online contenga informazioni più recenti di questo documento.