


## Sommario



## Set NEW Password

This modifies the password to access the system functions. The password is a number of max 3 digits. The default password is: **123** The procedure first asks for the current password (Actual Pwd) and, if correct, then allows a new password to be entered (New Pwd).



When the new password has been entered the “saving data...” message is given to indicate that the new data is being saved.

**NB: if 0 (zero) is entered as a new password, the password request is disabled.**

Documento generato automaticamente da **Qem Wiki** - <https://wiki.qem.it/>

Il contenuto wiki è costantemente aggiornato dal team di sviluppo, è quindi possibile che la versione online contenga informazioni più recenti di questo documento.