

Sommario

This procedure views and modifies the communication parameters of the ETHERNET port.
When the function is accessed all data saved on the controller is shown.



To change a parameter press @key@ and introduce the new setting.



Press ENTER to go to and change the next box.

When the last box is confirmed, the data is saved and the **“saving data...”** message is given.

If the Ethernet port is not present on the hardware, the message **“Function not enabled”** is given.

Documento generato automaticamente da **Qem Wiki** - <https://wiki.qem.it/>

Il contenuto wiki è costantemente aggiornato dal team di sviluppo, è quindi possibile che la versione online contenga informazioni più recenti di questo documento.