•					
			•		
	•	~		•	_
ш		a	•		_
		ч	•	•	_

Firmware	error	messages

When downloading the Qmove application, the QView-6 development environment can give error messages that are not described in the development environment manual. These errors are special and the description string given by QView-6 is generated directly by the firmware.

The table below describes possible error messages generated by the firmware.

## Firmware error messages

Possible error message	Description		
Error: SYSTEM + ARRSYS + DATAGROUP + INTDEVICE size overflow by 234bytes.	Given when the retentive variables exceed the maximum limit.		
Error: serial port not avaliable in SERCOM or MODBUS device declaration.	Given when the wrong number is used during the device declaration to select the communication channel.		
Error: CANOPEN device required if you use more than 3 slots.	In the BUS definition more than 3 slots are being used and so the application requests the use of Canopen modules. To manage this, a CANOPEN device must be declared.		
Error: incorrect bus fault mode in CANOPEN declaration.	The CANOPEN device declaration indicates a fault mode (last value in the declaration) that is not supported.		
Error: incorrect canbus speed in CANOPEN declaration.	The CANOPEN device declaration indicates an invalid speed.		
Error: too much CANOPEN device declaration.	Only one CANOPEN device can be declared.		
Error: absol. encoder resource num in ABSCNT device declar. is not avail.	The ABSCNT device declaration indicates an inexistent resource.		
Error: COUNT in ABSCNT device declaration is not a simulated counter.	The counter address used in the ABSCNT device declaration cannot be a simulated type (e.g. 1.CNT01).		
QMos version error. Unsupported instructions set.	One or more statements in the project QCL are not supported by the firmware.		
Error: compression file type not support.	The compression of the compiled QCL program is not supported by the firmware.		
Error: too mutch slots in bus declarations.	They were declared under BUS more slots than those allowed by the hardware.		

Documento generato automaticamente da **Qem Wiki** - https://wiki.qem.it/

Il contenuto wiki è costantemente aggiornato dal team di sviluppo, è quindi possibile che la versione online contenga informazioni più recenti di questo documento.