

Sommario

<i>Negative Transition-Sensing Toggle Contact</i>	3
--	---

Negative Transition-Sensing Toggle Contact

Function name	NTSTCN_010
Function version	1.0
Function state	stable
Compatibility with IEC61131-3	not compatible

Graphic symbol :



Input / Output :

Name	Belonging Group	Access	Types of data	Description
reference	Normal	R , RW	F , B , W , L , S	Reference variable of the contact

Description :

If the reference variable is FLAG type:

The state of the right link passes alternatively from OFF to ON (toggle) at each negative transition, from 1 (one) to 0 (zero), of the reference variable (indicated with **reference**). The state of the left link is ignored.

If the reference variable is BYTE, WORD, LONG and SINGLE type:

The state of the right link passes alternatively from OFF to ON (toggle) at each negative transition, from a value different from 0 (zero) to a value equal to 0 (zero), of the reference variable (indicated with **reference**). The state of the left link is ignored.

Documento generato automaticamente da **Qem Wiki** - <http://wiki.qem.it/>

Il contenuto wiki è costantemente aggiornato dal team di sviluppo, è quindi possibile che la versione online contenga informazioni più recenti di questo documento.