

## Sommario


|   |   |
|---|---|
| <b><i>Normally Open Contact</i></b> ..... | 3 |
|---|---|



## Normally Open Contact

|                                      |            |
|--------------------------------------|------------|
| <b>Function name</b>                 | NOCN_010   |
| <b>Function version</b>              | 1.0        |
| <b>Function state</b>                | stable     |
| <b>Compatibility with IEC61131-3</b> | compatible |

**Graphic symbol :**



**Input / Output :**

| Name      | Belonging Group | Access | Types of data     | Description                       |
|-----------|-----------------|--------|-------------------|-----------------------------------|
| reference | Normal          | R , RW | F , B , W , L , S | Reference variable of the contact |

**Description :**

**If the reference variable is FLAG type:**

The state of the left link is copied in the right link if the state of the associated boolean variable (indicated with **reference**) is ON, otherwise the state of the right link is OFF.

**If the reference variable is BYTE, WORD, LONG and SINGLE type:**

The state of the left link is copied in the right link if the value of the associated variable (indicated with **reference**) is different from 0 (zero), otherwise the state of the right link is OFF.

---

Documento generato automaticamente da **Qem Wiki** - <https://wiki.qem.it/>  
Il contenuto wiki è costantemente aggiornato dal team di sviluppo, è quindi possibile che la versione online contenga informazioni più recenti di questo documento.