


Sommario

<i>ACOS (Arc Cosine)</i>	3
---------------------------------------	---

ACOS (Arc Cosine)

Function name	ACOS_010
Function version	1.0
Function state	stable
Compatibility with IEC61131-3	not compatible

Graphic symbol :



Input / Output :

Name	Belonging Group	Access	Types of data	Description
EN	Left Power Flow			IEC1131-3 enable input
A	Normal	R , RW	F , B , W , L , S	Input Variable A
Q	Normal	W , RW	F , B , W , L , S	Result of the operation in radians $Q = \text{ACOS}(A)$
ENO	Right Power Flow			IEC1131-3 enable output

Description :

This function executes the operation Arc Cosine; it calculates the trigonometric function arccosine of the value A and place the result in Q. The output angle is in radians. To convert an angle from degrees to radians, you have to multiply it by 1.745329E-2 (corresponding to about $\pi / 180$).

Documento generato automaticamente da **Qem Wiki** - <https://wiki.qem.it/>

Il contenuto wiki è costantemente aggiornato dal team di sviluppo, è quindi possibile che la versione online contenga informazioni più recenti di questo documento.