

目录

VC10Copy	3
IMPLEMENTATION	3

VC10Copy

V = Variables

C = Calculation functions The VC10Copy function copy the value from a variable to another.

IMPLEMENTATION

VC10CollVal (val01, val02, val03, Result)

Parameters:

IN/OUT	VARIABLE TYPE	EXAMPLE NAME	DIM	
IN	SYSTEM	val01	L/S	First value to compare
IN	SYSTEM	val02	L/S	Second value to compare
IN	SYSTEM	val03	L/S	The value to compare with val01 and val02
OUT	SYSTEM	result	B	Variable containing the result of the comparison according to the truth table shown above

Example

Run the comparison when the “gfComp” flag is set to 1.

```
IF gfComp
  gfComp = 0
  val01 = 1000
  val02 = 5000
  VC10CollVal (val01, val02, val03, result)
ENDIF
```

Note

- The function execute a WAIT a time every 180 milliseconds

Documento generato automaticamente da **Qem Wiki** - <https://wiki.qem.it/>

Il contenuto wiki è costantemente aggiornato dal team di sviluppo, è quindi possibile che la versione online contenga informazioni più recenti di questo documento.