

Table of Contents

VC10Granularity	3
<i>IMPLEMENTATION</i>	3

VC10Granularity

V = Variables

C = Calculation functions

The VC10Granularity function displays a value with granularity and threshold filter.

IMPLEMENTATION

VC10Granularity (in, out, granularity, threshold)

Parameters:

IN/OUT	VARIABLE TYPE	EXAMPLE NAME	DIM	
IN	GLOBAL	in	W/L	Input value variable
OUT	GLOBAL	out	W/L	Output value variable
IN	CONST/GLOBAL	granularity	W/L	Granularity value variable
IN	CONST/GLOBAL	threshold	W/L	Threshold value variable

Example

Copy variable A to variable B

```
IF gfCopy
  gfCopy = 0
  vala = 1000
  valb = 5000
  dir = 1
  VC10Copy (dir, vala, valb)
ENDIF
```

Example

Copy variable B to variable A

```
IF gfCopy
  gfCopy = 0
  vala = 1000
  valb = 5000
  dir = 0
  VC10Copy (dir, vala, valb)
ENDIF
```

Note

- The function

Documento generato automaticamente da **Qem Wiki** - <https://wiki.qem.it/>

Il contenuto wiki è costantemente aggiornato dal team di sviluppo, è quindi possibile che la versione online contenga informazioni più recenti di questo documento.