

## Table of Contents

<b>VC10Granularity</b> .....	3
<b>IMPLEMENTATION</b> .....	3



**PRELIMINARY**

## VC10Granularity

**V** = *Variables*

**C** = *Calculation functions*

The VC10Granularity function displays a value with granularity and threshold filter.

## IMPLEMENTATION

### VC10Granularity (in, out, granularity, threshold)

Parameters:

IN/OUT	VARIABLE TYPE	EXAMPLE NAME	DIM	
IN	GLOBAL	in	W/L	Input value variable
OUT	GLOBAL	out	W/L	Output value variable
IN	CONST/GLOBAL	granularity	W/L	Granularity value variable
IN	CONST/GLOBAL	threshold	W/L	Threshold value variable



## Example

Copy variable A to variable B

```
IF gfCopy
    gfCopy = 0
    vala = 1000
    valb = 5000
    dir = 1
ENDIF
    VC10Copy (dir, vala, valb)
```



## Note

- The function

Documento generato automaticamente da **Qem Wiki** - <https://wiki.qem.it/>

Il contenuto wiki è costantemente aggiornato dal team di sviluppo, è quindi possibile che la versione online contenga informazioni più recenti di questo documento.