

Sommario

VR10SByToAsc 3

IMPLEMENTATION 3

 Errcode 3

VR10SByToAsc

V = Variables

R = Reading functions

SIGNED BYTE → ASCII

The VR10SByToAsc function converts a Signed Bytes variable type (byte with sign) in an Ascii variable type.

IMPLEMENTATION

VR10SByToAsc (value, index, array, errcode)

Parameters:

IN/OUT	VARIABLE TYPE	EXAMPLE NAME	DIM	
IN	GLOBAL	value	B	Data value to convert
IN	GLOBAL	index	L	Index of the array element to start the "deposit" of the converted data
OUT	ARRGBL	array	B	Array containing the converted data (must be declared at least "index" elements)
OUT	GLOBAL	errcode	F	Variable that indicates a possible error on the function

Errcode

After calling the function, 'errcode' can take certain values, the meaning of these values is summarized below:

0: No error

Example

Transforms the value 12 (signed byte) in a ASCII value

```
value = -12
index = 1
VR10SByToAsc (value, index, array, errcode)
;On the array will be :
; array[1] = 48
; array[2] = 67
```

Note

Documento generato automaticamente da **Qem Wiki** - <https://wiki.qem.it/>

Il contenuto wiki è costantemente aggiornato dal team di sviluppo, è quindi possibile che la versione online contenga informazioni più recenti di questo documento.