

## Sommario

|                            |   |
|----------------------------|---|
| SYSTEM BOOTING state ..... | 3 |
|----------------------------|---|



**SYSTEM BOOTING state**

During the SYSTEM BOOTING state instruments with displays, displays some important information about the system as in the example shown in the following figure:

```

SYSTEM BOOTING
Boot status: POWER-ON
Firmware: 1P44F-30.8.039
S/N: 12345678 - P/N:96000000
HW Rel: 01b0
PLD: MF028-02.0
Date(DMY)/Time: 31/12/2015 - 12:34:56
Dip-Switch = 0x2E
MMC: NOT PRESENT !
NAND: PRESENT 40510/63794 KB
USB: Mass Storage mode
Touch Screen: PRESENT
ETHERNET: IP = 192.168.0.253
          NM = 255.255.255.0
          GW = 0.0.0.0
BACKUP: VALID
          QCL App: 25/04/2001 - 16:58:07 MATCH
          QCL Dat: 25/04/2001 - 16:58:37 MATCH
          QTP App: 25/04/2001 - 17:01:15 MATCH
Press F1/FUNC for 2s to System Functions

```



**WARNING: The values shown in the figure are examples and may vary according to the instrument. Some values may not be present.**

**List of the information displayed**

| n. | Message  | Description  |
|----|--|--|
| 1  | Boot status: POWER-ON  | It displays the status of the boot:<br>POWER-ON Switching on the instrument<br>INIT Download application initialization<br>RESTART Restarting the instrument software<br>BACKUP Performing the Backup<br>RESTORE Performing the Restore  |
| 2  | Firmware: 1K31F-30.5.6   | They show the name, version, major releases and minor releases of firmware. In the example we have:<br>1K31F Firmware name<br>30 Version<br>5 Major release<br>6 Minor release (build)   |
| 3  | S/N: 12345678  | This displays the serial number of the instrument.   |
| 4  | P/N: 96000000  | This displays the part number of the instrument.   |
| 5  | HW Rel: 01b0   | This displays the hardware release of the instrument.  |
| 6  | PLD: MF028-02.0  | This displays the PLD of the instrument.   |
| 7  | Date(DMY)/Time: 31/12/2015 - 12:34:56                              | The clock/calendar is displayed in the format:<br>DD/MM/YYYY - hh:mm:ss  |
| 8  | Dip-Switch = 0x2E  | It displays a hexadecimal value representing the status of the switch SW1.<br>It is equivalent to the value of the system variable SYS002.   |
| 9  | MMC: NOT PRESENT !   | If a MMC/SD is inserted into the slot, at this stage we are displayed device data such as KB used and KB total.<br>In the case where the device is not present is displayed "MMC: NOT PRESENT !"   |
| 10 | NAND: PRESENT 40510/63794 KB                                       | It checks for all of the internal NAND, and then displays the KB used and KB total.<br>In the case where the device is not detected, an error is reported and is displayed "NAND: NOT PRESENT !"   |
| 11 | USB: Mass Storage mode   | It describes the using mode for the USB port ("Mass Storage" or "AOA").  |
| 12 | Touch Screen: PRESENT  | Instruments equipped with a touch screen, it is detected and then are verified the calibration data.<br>In the event that has yet to be performed calibration, the message displayed is "CALIBRATION REQUIRED !".<br>The touchscreen calibration is possible with the system function "Touch Calibration". |
| 13 | ETHERNET: IP = 192.168.0.253<br>NM = 255.255.255.0<br>GW = 0.0.0.0 | On instruments equipped with Ethernet interface, displays the parameters IP address (IP), subnet mask (NM) and Gateway (GW).<br>Changing these values is possible with the system function "Set Ethernet communic. parameter" or through special programs available within the development environment.    |

| n. | Message  | Description   |
|----|--|---|
| 14 | BACKUP: VALID<br>QCL App: 25/04/2001 - 16:58:07<br>MATCH<br>QCL Dat: 25/04/2001 - 16:58:37<br>MATCH<br>QTP App: 25/04/2001 - 17:01:15<br>MATCH | It is checked for a valid backup in NAND and then displays the data of date and time of backup files relating to the application QCL (QCL App), the application data QCL (QCL Dat) and to the application QTP (QTP App).<br>If after "BACKUP" is displayed "VALID" means that the backup can be successfully restored by system function "Restore from NAND".<br>If after "BACKUP" appears "NOT PRESENT" it means that the backup is not present.<br>If after "BACKUP" is displayed "NOT VALID" means that the backup can not be restored properly as the checksum of the three files that make up are not consistent with each other.<br>After each file (QCL App, QCL Dat and QTP App), in addition to the information of the date and time of creation, is also displayed further information:<br>"MATCH" indicates that the file is consistent with the running application.<br>"NO MATCH" indicates that the file is not consistent with the running application.<br>"SIZE ERROR" indicates that the size of the file is invalid, possibly because the writing procedure was not completed correctly.<br>"NOT PRESENT" indicates that the file is not present. |
| 15 | Press F1/FUNC for 2s to System Functions   | The display of this message indicates that the pressure for at least 2 seconds of the F1 key or the FUNC button provides access to system functions as described in the procedure. The message is displayed for 4 seconds.  |
| 16 | !!! WARNING detected !!!<br>Press FUNC or F1 to continue   | If during the previous phases, they are displayed some warning messages, which do not affect the operation of the system, to allow the operator to easily read the screen is waited a time of about 20 seconds.<br>To not wait and go before, press the F1 key or the FUNC button.  |
| 17 | !!! ERROR detected !!!<br>Press FUNC or F1 to continue   | Message displayed if the previous phases are displayed some error messages.<br>To continue, press the F1 key or the FUNC button.  |

Documento generato automaticamente da **Qem Wiki** - <https://wiki.qem.it/>

Il contenuto wiki è costantemente aggiornato dal team di sviluppo, è quindi possibile che la versione online contenga informazioni più recenti di questo documento.