

Sommario

| | |
|-----------------------------|---|
| BC21PushBuf | 3 |
| IMPLEMENTATION | 3 |
| Error | 3 |

BC21PushBuf

B = Buffer

C = Calculation functions

The BC21PushBuf function inserts a value into a FIFO memory. The function requires an input value in the '**NewElement**' variable and puts it in the memory.

IMPLEMENTATION

BC21PushBuf (Buffer, NewElement, ErrorCode, head, tail)

Parameters:

| IN/OUT | VARIABLE TYPE | EXAMPLE NAME | DIM | |
|--------|-----------------|--------------|---------|---|
| IN | ARRGBL/ ARRSYS | Buffer | B/W/L/S | Array containing the Buffer |
| IN | GLOBAL | NewElement | L/S/W/B | Variable containing the value to be placed in the buffer |
| OUT | GLOBAL | ErrorCode | F | Variable containing the error possibly occurred during insertion of the value |
| IN | GLOBAL / SYSTEM | head | L | Internal index |
| IN | GLOBAL / SYSTEM | tail | L | Internal index |

Error

After calling the function if there are any errors the error variable (ErrorCode) takes the following values:

0 - No error

1 - Data not entered due to: full memory.

Example

Inserts the value of the reference count of a device ring buffer of each front of the "gfInsVal" flags

```
MAIN:
    IF gfInsVal
        gfInsVal = 0
        NewElement = count:posit
        BC21PushBuf (Buffer, NewElement, ErrorCode, gl001, gl002)
    ENDIF
```

Note

- Using this feature is linked to the **BC21InitBuf** function that initializes the memory.
- Complementary to this function is the **BC21PopBuf** function that extracts a data from FIFO memory.

Documento generato automaticamente da **Qem Wiki** - <https://wiki.qem.it/>

Il contenuto wiki è costantemente aggiornato dal team di sviluppo, è quindi possibile che la versione online contenga informazioni più recenti di questo documento.