

## Sommario

<b>VI10GetUnusedBufferSize</b> .....	3
<b>IMPLEMENTATION</b> .....	3



## VI10GetUnusedBufferSize

**V** = *Vector*

**I** = *Image*

Function that is used to manage the Vector Image feature (object that resides on some Qpaint versions).

The VI10GetUnusedBufferSize function used to get the number of unused Buffer elements.

The buffer size is specified as the number of items directly in defining the array in the configuration file. Not all array buffer will be used for drawing operations, only part of it is actually used to process transactions. The part that is not used you learn through this function.

## IMPLEMENTATION

### VI10GetUnusedBufferSize (awBuffer, Elem)

Parameters:

IN/OUT	VARIABLE TYPE	EXAMPLE NAME	DIM	
IN	ARRSYS / ARRGBL	awBuffer	W	Array that serves as a buffer for instructions/data
OUT	GLOBAL	Elem	W	A variable that contains the number of elements not exploited in the Buffer

### Example

#### TASK\_00

```

MAIN:
VI10InitBuffer (awBuffer)           ;Initializes the Buffer
VI10GetUnusedBufferSize (awBuffer, Elem)   ;Counts the number of items that aren't used in the buffer
glElemNoUsed = Elem                 ;Copy number of unused in a variable
....
WAIT 1
JUMP MAIN
END

```

### Note

Documento generato automaticamente da **Qem Wiki** - <https://wiki.qem.it/>

Il contenuto wiki è costantemente aggiornato dal team di sviluppo, è quindi possibile che la versione online contenga informazioni più recenti di questo documento.