

Sommario

| | |
|-----------------------------|---|
| VR10BinToSWr | 3 |
| IMPLEMENTATION | 3 |
| Errcode | 3 |

VR10BinToSWr

V = Variables

R = Reading function

BINARY → SIGNED WORD

The VR10BinToSWr function converts a signed binary variable type in a Word type (word with sign).

IMPLEMENTATION

VR10BinToSWr (array, index, return, errcode)

Parameters:

| IN/OUT | VARIABLE TYPE | EXAMPLE NAME | DIM | |
|--------|---------------|--------------|-----|--|
| IN | ARRGBL | array | B | Array containing the data to be converted (must be declared with at least "index + 1" items) |
| IN | GLOBAL | index | L | Index of the array element at the beginning of the data |
| OUT | GLOBAL | return | W | Data value converted |
| OUT | GLOBAL | errcode | F | Variable that indicates a possible error on the function |

Errcode

After calling the function, 'errcode' can take certain values, the meaning of these values is summarized below:
0: No error

Example

Transforms the value (binary) in an signed word value

```
index = 1
array[1] = 1
array[2] = 80
VR10BinToSWr (array, index, return, errcode)
;On the return you will find :
; return = 336
```

Note

Documento generato automaticamente da **Qem Wiki** - <https://wiki.qem.it/>

Il contenuto wiki è costantemente aggiornato dal team di sviluppo, è quindi possibile che la versione online contenga informazioni più recenti di questo documento.