

Table of Contents

VR10SWrToBin	3
IMPLEMENTATION	3
Errcode	3

VR10SWrToBin

V = *Variables*

R = *Reading functions*

SIGNED WORD → BINARY

The VR10SWrToBin function Converts a Signed Word variable type (word with sign) in a Binary variable type.

IMPLEMENTATION

VR10SWrToBin (value, index, array, errcode)

Parameters:

IN/OUT	VARIABLE TYPE	EXAMPLE NAME	DIM	
IN	GLOBAL	value	W	Data value to convert
IN	GLOBAL	index	L	Index of the array element to start the “deposit” of the converted data
OUT	ARRGBL	array	B	Array containing the converted data (must be declared with at least “index + 1” items)
OUT	GLOBAL	errcode	F	Variable that indicates a possible error on the function

Errcode

After calling the function, 'errcode' can take certain values, the meaning of these values is summarized below:

0: No error

Example

Transforms the value -100 (signed word) in a binary value

```
value = -100
index = 1
VR10SWrToBin (value, index, array, errcode)
;On the array will be :
; array[1] = -1
; array[2] = -20
```

Note

Documento generato automaticamente da **Qem Wiki** - <https://wiki.qem.it/>

Il contenuto wiki è costantemente aggiornato dal team di sviluppo, è quindi possibile che la versione online contenga informazioni più recenti di questo documento.