

Índice

AC11ResetArr	3
IMPLEMENTATION	3

AC11ResetArr

A = Array

C = Calculation Functions

The AC11ResetArr function executess a reset of all the elements of an array, signaling the completion of the operation.

IMPLEMENTATION

AC11ResetArr (array, done)

Parameters:

IN/OUT	VARIABLE TYPE	EXAMPLE NAME	DIM	
IN	ARRSYS / ARRGBL	array	B/W L/S	Array to reset
OUT	GLOBAL	done	F	Flag that indicates that the operation was executed

Example

Run the reset when this “gfReset” flag is set to 1.

```
<code QCL> IF gfReset
```

```
gfReset = 0
AC11ResetArr (array, done)
```

```
ENDIF
```

Note

- The function executes a WAIT a time every 180 milliseconds.

Documento generato automaticamente da **Qem Wiki** - <https://wiki.qem.it/>

Il contenuto wiki è costantemente aggiornato dal team di sviluppo, è quindi possibile che la versione online contenga informazioni più recenti di questo documento.