

目录

VC10Copy	3
IMPLEMENTATION	3

VC10Copy

V = Variables

C = Calculation functions The VC10Copy function copies the value from a variable to another.

IMPLEMENTATION

VC10Copy (val01, val02)

Parameters:

IN/OUT	VARIABLE TYPE	EXAMPLE NAME	DIM
IN	GLOBAL	dir	F Activation variable
IN	SYSTEM	vala	F First variable
IN	SYSTEM	valb	F Second variable

Example

Run the comparison when the “gfComp” flag is set to 1.

```
IF gfComp
  gfComp = 0
  val01 = 1000
  val02 = 5000
  VC10CollVal (val01, val02, val03, result)
ENDIF
```

Note

- The function execute a WAIT a time every 180 milliseconds

Documento generato automaticamente da **Qem Wiki** - <https://wiki.qem.it/>

Il contenuto wiki è costantemente aggiornato dal team di sviluppo, è quindi possibile che la versione online contenga informazioni più recenti di questo documento.