

Sommario

**VC10TCoupleT** ..... 3

**IMPLEMENTATION** ..... 3

        Error ..... 3



## VC10TCoupleT

The VC10TCoupleT function Converts a voltage value, expressed in microvolts, to the corresponding temperature value, expressed in tenths of a Celsius degree, connected with a thermocouple type T.

Input range : from -5600  $\mu\text{V}$  to 21000  $\mu\text{V}$

Output range : from -1998  $^{\circ}\text{C}^{-1}$  to 4020  $^{\circ}\text{C}^{-1}$

## IMPLEMENTATION

### VC10TCoupleT (mvhot, dgradi\_hot, gbError)

Parameters:

IN/OUT	VARIABLE TYPE	EXAMPLE NAME	DIM	
IN	GLOBAL	mvhot	L	It is the voltage value to convert expressed in micro Volts.
OUT	GLOBAL	dgradi_hot	L	It is the converted temperature value expressed in tenths of a Celsius degree.
OUT	GLOBAL	gbError	B	Variable containing the error code

### Error

Once invoked the function if there are any errors the error variable having the following values:

0 - No error

1 - Value less than the minimum

2 - Value higher than the maximum

3 - Value indicating disconnected input

### Example

```
...
; Cold-junction reading
card_type = 0 ; using L1TT0 card
IR10CJRead (COLD, card_type, dgradi_cold, error)
...
; Hot-junction reading
card_type = 0
IR10HJRead (HOT, card_type, mvhot, error)
...
VC10TCoupleT (mvhot, dgradi_hot, gbError)
...
temperature = dgradi_cold + dgradi_hot
...
```

Documento generato automaticamente da **Qem Wiki** - <https://wiki.qem.it/>

Il contenuto wiki è costantemente aggiornato dal team di sviluppo, è quindi possibile che la versione online contenga informazioni più recenti di questo documento.