

Inhaltsverzeichnis

VR10AscToUWr	3
IMPLEMENTATION	3
Errcode	3

VR10AscToUWr

V = Variables

R = Reading functions

ASCII → UNSIGNED WORD

The VR10AscToUWr function converts an Ascii variable type in an Unsigned Word type (word without sign).

IMPLEMENTATION

VR10AscToUWr (array, index, return, errcode)

Parameters:

IN/OUT	VARIABLE TYPE	EXAMPLE NAME	DIM	
IN	ARRGBL	array	B	Array containing the data to be converted (must be declared with at least „index + 3“ items)
IN	GLOBAL	index	L	Index of the array element at the beginning of the data
OUT	GLOBAL	return	L	Data value converted
OUT	GLOBAL	errcode	F	Variable that indicates a possible error on the function

Errcode

After calling the function, 'errcode' can take certain values, the meaning of these values is summarized below:

0: No error

1: Error: ASCII value is not within 48÷57 or 65÷70

Example

Transform the Ascii value D832h (55346 DEC) in an unsigned word value

```
index = 1
array[1] = 68
array[2] = 56
array[3] = 51
array[4] = 50
VR10AscToUWr (array, index, return, errcode)
;On the return data you will find :
; return = 55346
```

Note

Documento generato automaticamente da **Qem Wiki** - <https://wiki.qem.it/>

Il contenuto wiki è costantemente aggiornato dal team di sviluppo, è quindi possibile che la versione online contenga informazioni più recenti di questo documento.